

POSONIC

EX10 & EX18

System Programming Guide

Software Versions 4.8 (EX10) and 4.2 (EX18)

Installer Code (default - EX10: 282828; EX18: 383838)

Full access to programming, except user access codes (PINs). No access to arming/disarming. Use only numeric keys from [0] to [9].

Zone Recognition

Table 1: Zone Recognition

Device connected to which input?	EX10 No ATZ	EX10 With ATZ	EX18 No ATZ	EX18 With ATZ
Control Panel				
Input 1 =	Zone 1	Zones 1 & 2	Zone 1	Zones 1 & 9
Input 2 =	Zone 2	Zones 3 & 4	Zone 2	Zones 2 & 10
Input 3 =	Zone 3	Zones 5 & 6	Zone 3	Zones 3 & 11
Input 4 =	Zone 4	Zones 7 & 8	Zone 4	Zones 4 & 12
Input 5 =	N/A	N/A	Zone 5	Zones 5 & 13
Input 6 =	N/A	N/A	Zone 6	Zones 6 & 14
Input 7 =	N/A	N/A	Zone 7	Zones 7 & 15
Input 8 =	N/A	N/A	Zone 8	Zones 8 & 16
Keypad				
Zone 1 =	Zone 5	Zone 9	Zone 9	Zone 17
Zone 2 =	Zone 6	Zone 10	Zone 10	Zone 18

Streamlined Section Programming

This is an alternate method to Hex Programming (see page 2). Addresses **000** to **043** and **300** to **527** are grouped into 68 sections where each section contains four addresses (i.e. section **00** = addresses **000** to **003**). Using this method allows you to program 8 digits (4 addresses) without having to exit and re-enter addresses.



The keypad will not display the current data in the Streamlined Section Programming method.

Table 2: Streamlined Section Programming Method

1. Press [ENTER] + [INSTALLER CODE] (default - EX10: 282828; EX18: 383838) + [7].
2. The [ENTER] and [2ND] keys will flash to indicate you are in programming mode (LED keypad only).
3. Enter 2-digit [SECTION] (00 to 67).
4. The [ENTER] key will remain on while the [2ND] key will be off (LED keypad only).
5. Enter 8-digit [DATA] to program the section.
6. The keypad will beep to indicate that the section has been programmed, data is saved and the software has advanced to the next section.
7. Return to step 4 or press [CLEAR] to exit programming mode.

Keypad Trouble Display

Press the **[TBL]/[TRBL]** key to view the trouble. Any illuminated keys represent a specific trouble as indicated in *Table 3* below. Press the **[CLEAR]** button to exit the trouble display.

Table 3: Trouble Display

[1] - No Battery or Low Voltage	[7] - Communicator Report Failure
[2] - Power Failure	[8] - Timer Loss* (to clear, see [MEM] key in <i>Table 11</i> on page 11)
[4] - Bell Output Disconnected	[9] - Tamper or Zone Wiring Failure
[5] - Exceeded Maximum Bell Current	[10] - Telephone Line Monitoring Failure
[6] - Exceeded Maximum Auxiliary Current	[11] - Fire Loop Trouble


Hex Programming

This is an alternate method to the Streamlined Section Programming (see page 1). Addresses **000** to **043** and **300** to **527** can be programmed using the Hex Programming method. In this mode, you can enter any hexadecimal digit from 0 to F where keys **[1]** to **[9]** represent digits 1 to 9 respectively; the other keys represent hexadecimal digits A to F as shown in Figure 1 below.


Table 4: Hex Programming Method

1. Press **[ENTER]** + **[INSTALLER CODE]** (EX10: **282828**; EX18: **383838**).
2. The **[ENTER]** key will flash indicating you are in programming mode (LED keypad only).
3. Enter the desired 3-digit **[ADDRESS]**.
4. The keypad will display the 2-digit data currently saved at this address as described in Figure 1 below.
5. Enter 2-digit **[DATA]** and do not press **[ENTER]**, the software automatically saves the data.
6. Return to step 2 or press **[CLEAR]** to exit programming mode.

Figure 1: Hex Digit Data Entry and Data Display for LED Keypads



Installer / Panel Answer Options



Streamline Section	Data	Description	Address	
01	____ / ____	Panel Identifier (1st, 2nd digit)	004	{ Identifies the control panel to the PC.
	____ / ____	Panel Identifier (3rd, 4th digit)	005	
	____ / ____	PC Password (1st, 2nd digit)	006	{ Identifies the PC to the control panel.
	____ / ____	PC Password (3rd, 4th digit)	007	

Telephone and Account Numbers

If only one monitoring station telephone number is used, program the same number for telephone numbers 1 and 2. If only one account number is required, the same number must be entered for both accounts "A" and "B".

[0] to [9] = numeric value [BYP] = switch from pulse to tone while dialing
 [STAY] = * [MEM] = pause 4 seconds
 [AWAY]/[FORCE] = # [TBL]/[TRBL] = end of number

Computer Telephone Number (View at addresses 008 to 015)

Streamline Section	Streamline Section	Press the [TBL]/[TRBL] key to end phone number if less than 16 digits are programmed.
02 ____ / ____ / ____ / ____ 1 2 3 4 5 6 7 8	03 ____ / ____ / ____ / ____ 9 10 11 12 13 14 15 16	

Monitoring Station Telephone Number 1 (View at addresses 016 to 023)

Streamline Section	Streamline Section	Press the [TBL]/[TRBL] key to end phone number if less than 16 digits are programmed.
04 ____ / ____ / ____ / ____ 1 2 3 4 5 6 7 8	05 ____ / ____ / ____ / ____ 9 10 11 12 13 14 15 16	

Monitoring Station Telephone Number 2 (View at addresses 024 to 031)

Streamline Section	Streamline Section	Press the [TBL]/[TRBL] key to end phone number if less than 16 digits are programmed.
06 ____ / ____ / ____ / ____ 1 2 3 4 5 6 7 8	07 ____ / ____ / ____ / ____ 9 10 11 12 13 14 15 16	

Accounts "A" and "B" (View at addresses 032 to 035)

Streamline Section	For 3-digit account numbers, enter "skip" ([2ND]) as first digit. The Standard Pulse report format can support 3- or 4-digit account numbers. The Ademco Express, Ademco Contact ID and the Pager report formats only support 4-digit account numbers.
08 ____ / ____ ____ / ____ 1 2 3 4 5 6 7 8 A B	

Streamline Section	Data	Description	Address	Pager Delay Table (1st digit)
09	[2ND] / [2ND]	Future Use	036	[2ND] or [1] = 8s [9] = 72s
	___ / ___	1st digit: Pager Delay (see table at right) 2nd digit: Time correction (see table at right)	037	[2] = 16s [0] = 80s
	___ / ___	1st digit: Communicator Format 1 2nd digit: Communicator Format 2	038	[3] = 24s [STAY] = 88s
	___ / ___	1st digit: PGM1 type 2nd digit: PGM2 type (EX18 only)	039	[4] = 32s [FORCE]/[AWAY] = 96s
10	___ / ___	PGM1	040	[5] = 40s [BYP] = 104s
	___ / ___	PGM2 (738 Ultra only)	041	[6] = 48s [MEM] = 112 s
	___ / ___	PGM Mask 1	042	[7] = 56s [TBL]/[TRBL] = 120s
	___ / ___	PGM Mask 2 (EX18 only)	043	[8] = 64s

Time Correction Table (2nd digit)

[2ND] = No adjustment	[8] = Minus 4s
[1] = Plus 4s	[9] = Minus 8s
[2] = Plus 8s	[0] = Minus 12s
[3] = Plus 12s	[STAY] = Minus 16s
[4] = Plus 16s	[FORCE] = Minus 20s
[5] = Plus 20s	[BYP] = Minus 24s
[6] = Plus 24s	[MEM] = Minus 28s
[7] = Plus 28s	[TRBL] = Minus 32s

Communicator Formats (* = supports 4-digit account codes only)

Key	
[2ND]	= ADEMCO slow (1400Hz, 1900Hz, 10bps)
[1]	= (1400Hz, 1800Hz, 10bps)
[2]	= SILENT KNIGHT fast (1400Hz, 1900Hz, 20bps)
[3]	= SESCOA (2300Hz, 1800Hz, 20bps)
[4]	= RADIONICS (40bps with 1400Hz handshake)
[5]	= RADIONICS (40bps with 2300Hz handshake)
[6]	= RADIONICS with PARITY (1400Hz, 40bps)
[7]	= RADIONICS with PARITY (2300Hz, 40bps)
[8]	= * ADEMCO express
[9]	= * ADEMCO contact ID (programmable codes)
[0]	= * ADEMCO contact ID (all codes)
[TBL] / [TRBL]	= * PAGER FORMAT (personal dialing)

Programmable Contact ID Event Codes

All addresses from 300 to 527 (sections 11 to 67) programmed with values other than [2ND] [2ND] will report the contact ID codes corresponding to the values programmed. Values to be programmed should be selected from this table.

CID	Reporting Code	Prog. Value	CID	Reporting Code	Prog. Value
100:	AUXILIARY ALARM	[2ND] / [1]	300:	SYSTEM TROUBLE	[2] / [2]
110:	FIRE ALARM	[2ND] / [2]	301:	AC LOSS	[2] / [3]
111:	FIRE SMOKE	[2ND] / [3]	302:	LOW SYSTEM BATTERY	[2] / [4]
112:	COMBUSTION	[2ND] / [4]	305:	SYSTEM RESET	[2] / [5]
113:	WATER FLOW	[2ND] / [5]	306:	PROGRAM CHANGED	[2] / [6]
114:	HEAT	[2ND] / [6]	309:	BATTERY TEST FAIL	[2] / [7]
115:	PULLSTATION	[2ND] / [7]	320:	SONDER/RELAY TROUBLE	[2] / [8]
116:	DUCT	[2ND] / [8]	321:	BELL 1 TROUBLE	[2] / [9]
117:	FLAME	[2ND] / [9]	323:	ALARM RELAY TROUBLE	[2] / [0]
118:	NEAR ALARM	[2ND] / [0]	350:	COMMUNICATION TROUBLE	[2] / [STAY]
120:	PANIC ALARM	[2ND] / [STAY]	351:	TELCO 1 FAULT	[2ND] / [AWAY] OR [FORCE]
121:	DURESS	[2ND] / [AWAY] OR [FORCE]	354:	FAIL TO COMMUNICATE	[2] / [BYP]
122:	SILENT PANIC	[2ND] / [BYP]	370:	PROTECTION LOOP TROUBLE	[2] / [MEM]
123:	AUDIBLE PANIC	[2ND] / [MEM]	371:	PROTECTION LOOP OPEN	[2] / [TRBL]
130:	BURGLARY	[2ND] / [TRBL]	372:	PROTECTION LOOP SHORT	[3] / [2ND]
131:	PERIMETER BURGLARY	[1] / [2ND]	373:	FIRE LOOP TROUBLE	[3] / [1]
132:	INTERIOR BURGLARY	[1] / [1]	382:	SENSOR TROUBLE	[3] / [2]
133:	24HR BURGLARY	[1] / [2]	383:	SENSOR TAMPER	[3] / [3]
136:	BURGLARY OUTDOOR	[1] / [3]	400:	OPEN / CLOSE	[3] / [4]
137:	BURGLARY TAMPER	[1] / [4]	401:	OPEN / CLOSE BY USER #	[3] / [5]
138:	BURGLARY NEAR ALARM	[1] / [5]	402:	GROUP OPEN / CLOSE	[3] / [6]
140:	GENERAL ALARM	[1] / [6]	403:	AUTOMATIC OPENING / CLOSING	[3] / [7]
150:	24 HOUR AUXILIARY	[1] / [7]	404:	LATE TO OPEN / CLOSE	[3] / [8]
151:	GAS DETECTED	[1] / [8]	407:	REMOTE ARM DOWNLOAD	[3] / [9]
152:	REFRIGERATION	[1] / [9]	410:	REMOTE ACCESS	[3] / [0]
153:	LOSS OF HEAT	[1] / [0]	441:	OPEN / CLOSE - STAY MODE	[3] / [STAY]
154:	WATER LEAKAGE	[1] / [STAY]	570:	BYPASS	[3] / [AWAY] OR [FORCE]
155:	FOIL BREAK ALARM	[1] / [AWAY] OR [FORCE]	572:	24 HOUR ZONE BYPASS	[3] / [BYP]
156:	DAY TROUBLE ALARM	[1] / [BYP]	573:	BURGLARY BYPASS #	[3] / [MEM]
157:	LOW GAS LEVEL	[1] / [MEM]	574:	GROUP BYPASS	[3] / [TRBL]
158:	HIGH TEMPERATURE	[1] / [TRBL]	601:	MANUAL TEST	[4] / [2ND]
159:	LOW TEMPERATURE	[2] / [2ND]	602:	PERIODIC TEST	[4] / [1]
161:	LOSS AIR FLOW	[2] / [1]	625:	TIME / DATE RESET	[4] / [2]
			654:	SYSTEM INACTIVITY	[4] / [3]

Reporting Codes

All digits from [1] to [F] are valid. [2ND] = digit will not be reported except for Contact ID programmable codes. For single digit reporting, enter "skip" ([2ND]) as the first digit (default = [2ND] / [2ND]).

⚠ Enter FF to program the default Ademco Contact ID report code when using the Ademco Contact ID (programmable codes) or Pager report formats.
If the Contact ID Format (all codes) is selected, addresses 300 to 527 (sections 11 to 67) do not have to be programmed. To select Contact ID (all codes) you must set key [0] at section 09/address 038 for both monitoring station numbers (see page 4).

Arming (Closing) Report Codes:

Streamline Section	Data	Description	Address	Streamline Section	Data	Description	Address
11	____ / ____	Auto / Esupload	300	17	____ / ____	User Code 23	324
	____ / ____	Master	301		____ / ____	User Code 24	325
	____ / ____	User Code 1	302		____ / ____	User Code 25	326
	____ / ____	User Code 2	303		____ / ____	User Code 26	327
12	____ / ____	User Code 3	304	18	____ / ____	User Code 27	328
	____ / ____	User Code 4	305		____ / ____	User Code 28	329
	____ / ____	User Code 5	306		____ / ____	User Code 29	330
	____ / ____	User Code 6	307		____ / ____	User Code 30	331
13	____ / ____	User Code 7	308	19	____ / ____	User Code 31	332
	____ / ____	User Code 8	309		____ / ____	User Code 32	333
	____ / ____	User Code 9	310		____ / ____	User Code 33	334
	____ / ____	User Code 10	311		____ / ____	User Code 34	335
14	____ / ____	User Code 11	312	20	____ / ____	User Code 35	336
	____ / ____	User Code 12	313		____ / ____	User Code 36	337
	____ / ____	User Code 13	314		____ / ____	User Code 37	338
	____ / ____	User Code 14	315		____ / ____	User Code 38	339
15	____ / ____	User Code 15	316	21	____ / ____	User Code 39	340
	____ / ____	User Code 16	317		____ / ____	User Code 40	341
	____ / ____	User Code 17	318		____ / ____	User Code 41	342
	____ / ____	User Code 18	319		____ / ____	User Code 42	343
16	____ / ____	User Code 19	320	22	____ / ____	User Code 43	344
	____ / ____	User Code 20	321		____ / ____	User Code 44	345
	____ / ____	User Code 21	322		____ / ____	User Code 45	346
	____ / ____	User Code 22	323		____ / ____	User Code 46	347
23	____ / ____	See previous section		23	____ / ____	User Code 47	348
	____ / ____	Auto / Esupload	350		____ / ____	User Code 48 / (Duress)	349
	____ / ____	Master	351				
24	____ / ____	User Code 1	352	25	____ / ____	User Code 5	356
	____ / ____	User Code 2	353		____ / ____	User Code 6	357
	____ / ____	User Code 3	354		____ / ____	User Code 7	358
	____ / ____	User Code 4	355		____ / ____	User Code 8	359
26	____ / ____	User Code 9	360	26	____ / ____	User Code 10	361
	____ / ____	User Code 11	362		____ / ____	User Code 11	362
	____ / ____	User Code 12	363		____ / ____	User Code 12	363

Continues in next section.

Disarming (Opening) Report Codes (reset code "empty"):

Streamline Section	Data	Description	Address	Streamline Section	Data	Description	Address
23	____ / ____	See previous section		25	____ / ____	User Code 5	356
	____ / ____	Auto / Esupload	350		____ / ____	User Code 6	357
24	____ / ____	Master	351	26	____ / ____	User Code 7	358
	____ / ____				____ / ____	User Code 8	359
	____ / ____	User Code 1	352		____ / ____	User Code 9	360
	____ / ____	User Code 2	353		____ / ____	User Code 10	361
25	____ / ____	User Code 3	354		____ / ____	User Code 11	362
	____ / ____	User Code 4	355		____ / ____	User Code 12	363

Disarming (Opening) Report Codes (reset code “empty”):
(continued)

Streamline Section	Data	Description	Address	Streamline Section	Data	Description	Address
27	____ / ____	User Code 13	364	31	____ / ____	User Code 29	380
	____ / ____	User Code 14	365		____ / ____	User Code 30	381
	____ / ____	User Code 15	366		____ / ____	User Code 31	382
	____ / ____	User Code 16	367		____ / ____	User Code 32	383
28	____ / ____	User Code 17	368	32	____ / ____	User Code 33	384
	____ / ____	User Code 18	369		____ / ____	User Code 34	385
	____ / ____	User Code 19	370		____ / ____	User Code 35	386
	____ / ____	User Code 20	371		____ / ____	User Code 36	387
29	____ / ____	User Code 21	372	33	____ / ____	User Code 37	388
	____ / ____	User Code 22	373		____ / ____	User Code 38	389
	____ / ____	User Code 23	374		____ / ____	User Code 39	390
	____ / ____	User Code 24	375		____ / ____	User Code 40	391
30	____ / ____	User Code 25	376	34	____ / ____	User Code 41	392
	____ / ____	User Code 26	377		____ / ____	User Code 42	393
	____ / ____	User Code 27	378		____ / ____	User Code 43	394
	____ / ____	User Code 28	379		____ / ____	User Code 44	395
35	____ / ____	User Code 45	396	35	____ / ____	User Code 46	397
	____ / ____	User Code 47	398		____ / ____	User Code 48 / (Duress)	399
	____ / ____				____ / ____		
	____ / ____				____ / ____		

Alarm Report Codes For Zones 1 to 10 (18) †:

Streamline Section	Data	Description	Address
36	____ / ____	Zone 1	400
	____ / ____	Zone 2	401
	____ / ____	Zone 3/Fire zone* (fire address 100)	402
	____ / ____	Zone 4	403
37	____ / ____	Zone 5/Fire zone**	404
	____ / ____	Zone 6	405
	____ / ____	Zone 7	406
	____ / ____	Zone 8	407
38	____ / ____	Zone 9	408
	____ / ____	Zone 10	409
	____ / ____	Zone 11 (EX18 only)	410
	____ / ____	Zone 12 (EX18 only)	411
39 738 Ultra only	____ / ____	Zone 13	412
	____ / ____	Zone 14	413
	____ / ____	Zone 15	414
	____ / ____	Zone 16	415
40 738 Ultra only	____ / ____	Zone 17	416
	____ / ____	Zone 18	417

Alarm Restore Report Codes For Zones 1 to 10 (18) †:

Streamline Section	Data	Description	Address
42	____ / ____	Zone 1	424
	____ / ____	Zone 2	425
	____ / ____	Zone 3/Fire zone* (fire address 100)	426
	____ / ____	Zone 4	427
43	____ / ____	Zone 5/Fire zone**	428
	____ / ____	Zone 6	429
	____ / ____	Zone 7	430
	____ / ____	Zone 8	431
44	____ / ____	Zone 9	432
	____ / ____	Zone 10	433
	____ / ____	Zone 11 (EX18 only)	434
	____ / ____	Zone 12 (EX18 only)	435
45 EX18 only	____ / ____	Zone 13	436
	____ / ____	Zone 14	437
	____ / ____	Zone 15	438
	____ / ____	Zone 16	439
46 EX18 only	____ / ____	Zone 17	440
	____ / ____	Zone 18	441

41

Future Use

418 - 423
47

Future Use

442 - 447

* = Fire zone for 4-wire smoke detectors or 2-wire smoke detectors (with no ATZ enabled—EX10 only).

** = Fire zone for 2-wire smoke detectors (address 086, key **[BYP]**) only when ATZ is enabled (address 090, key **[8]**). Applies only to EX10.

† = Zones 1 to 10 for the 738 Ultra and Zones 1 to 18 for the EX18

Zones 1 to 10 (18)† Shutdown Report Codes:

Streamline Section	Data	Description	Address
48	____/____	Zone 1	448
	____/____	Zone 2	449
	____/____	Zone 3	450
	____/____	Zone 4	451
49	____/____	Zone 5	452
	____/____	Zone 6	453
	____/____	Zone 7	454
	____/____	Zone 8	455
50	____/____	Zone 9	456
	____/____	Zone 10	457
	____/____	Zone 11 (EX18 only)	458
	____/____	Zone 12 (EX18 only)	459
51	____/____	Zone13	460
	____/____	Zone 14	461
	____/____	Zone 15	462
	____/____	Zone 16	463
52	____/____	Zone17	464
	____/____	Zone 18	465
53		Future Use	466 - 471

Tampers 1 to 4, 5 and 7 (8)‡ Report Codes:

Streamline Section	Data	Description	Address
54	____/____	Tamper 1	472
	____/____	Tamper 2	473
	____/____	Tamper 3	474
	____/____	Tamper 4	475
55	____/____	Tamper 5	476
	____/____	Tamper 6 (EX18 only)	477
	____/____	Tamper 7	478
	____/____	Tamper 8 (EX18 only)	479
56 to 59		Future Use	480 - 495

† = Zones 1 to 10 for the EX10 and
Zones 1 to 18 for the EX18

‡ = Zones 1 to 4, 5 and 7 for EX10 and
Zones 1 to 8 for EX18

Trouble Report Codes:

Streamline Section	Data	Description	Address
60	____/____	Max. aux. current	496
	____/____	Bell disconnect / max. bell current	497
	____/____	Battery disconnect / low voltage	498
	____/____	Power failure	499

Streamline Section	Data	Description	Address
61	____/____	Fire loop trouble	500
	____/____	Timer loss	501
	[2ND]/[2ND]	Future Use	502
	[2ND]/[2ND]	Future Use	503

Trouble Restore Report Codes:

Streamline Section	Data	Description	Address
62	____/____	Max. aux. current	504
	____/____	Bell disconnect / max. bell current	505
	____/____	Battery disconnect / low voltage	506
	____/____	Power failure	507

Streamline Section	Data	Description	Address
63	____/____	Fire loop trouble	508
	____/____	Timer programmed	509
	____/____	Tamper / wiring fault	510
	____/____	TLM restore	511

Special Report Codes:

Streamline Section	Data	Description	Address
64	____/____	Test report	512
	____/____	Panic 1	513
	____/____	Panic 2	514
	____/____	Panic 3	515
65	____/____	Late to close	516
	____/____	No movement	517
	____/____	Partial Arming	518
	____/____	Recent Close	519

Streamline Section	Data	Description	Address
66	____/____	Duress	520
	____/____	Closing Delinquency	521
	[2ND]/[2ND]	Future Use	522
	[2ND]/[2ND]	Future Use	523
67	____/____	Login (Espload)	524
	____/____	Program Change	525
	[2ND]/[2ND]	Future Use	526
	[2ND]/[2ND]	Future Use	527

Decimal Programming

The decimal programming method is used to program all of the system's timers. This method uses a 3-digit address from **044** to **061** and each address is programmed with a value from **000** to **255**.


Table 5: Decimal Programming Method

1. Press **[ENTER]** + **[INSTALLER CODE]** (default - EX10: **282828**; EX18: **383838**)
2. The **[ENTER]** key will flash to indicate that you are in programming mode (LED keypad only).
3. Enter 3-digit **[ADDRESS]** (**044** to **061**).
4. The keypad displays the current 3-digit data saved at this address as described in *Figure 2* below.
5. Enter 3-digit **[DATA]** (000 to 255) and do **not** press **[ENTER]**. The software will automatically save the data.
6. Return to step 2 or press **[CLEAR]** to exit programming mode.


Address	Data	Description	Default
044	__ / __ / __	(hours) Auto arm time (between "000" and "023")	000
045	__ / __ / __	(minutes) Auto arm time (between "000" and "059")	000
046	__ / __ / __	(days or hours) Auto test report every ? (between "001" and "254") (000 = disabled) If address 090 key [3] OFF = address 046 in days (see page 10) If address 090 key [3] ON = address 046 in hours (see page 10) EX18 only: Enter "255" to enable a Timed Test Transmission when the system is armed or disarmed (see the "728 Ultra/738 Ultra Reference & Installation Manual" for more information)	000
047	__ / __ / __	(hours) Auto test report (between "000" and "023") EX18 only: (minutes) If address 046 = 255 and the system is armed, Armed Test Report (between "001" and "255")	000
048	__ / __ / __	(minutes) Auto test report (between "000" and "059") EX18 only: (minutes) If address 046 = 255 and the system is disarmed, Disarmed Test Report (between "001" and "255")	000
049	__ / __ / __	(seconds) Exit delay	60 seconds
050	__ / __ / __	(seconds) Entry delay 1	45 seconds
051	__ / __ / __	(seconds) Entry delay 2	45 seconds
052	__ / __ / __	(minutes) Bell cut-off time	5 minutes
053	__ / __ / __	(x 15 ms) Zone speed	600 ms
054	__ / __ / __	(minutes) Power failure report delay (000 = disabled)	30 minutes
055	__ / __ / __	(x 15 minutes) No movement Auto-Arm time (000 = disabled)	Disabled
056	__ / __ / __	PGM timer setting (001 to 127 for seconds and 129 to 255 for minutes) Add 128 to desired value in minutes (i.e. for 5 minutes: enter 5 + 128 = 133)	5 seconds
057	__ / __ / __	Intellizone delay (in seconds, minimum = 10 seconds)	48 seconds
058	__ / __ / __	Installer code lock (147 = locked, 000 = unlocked). When Installer Lock is enabled on a control panel: For 4 seconds during power up, the STATUS LED flashes while the dialer relay opens and closes making a clicking noise.	Unlocked
059	__ / __ / __	(seconds) Programmable delay before alarm transmission (005 to 063 seconds) (000 = disabled)	Disabled
060	__ / __ / __	(seconds) Recent closing delay (000 = disabled)	Disabled
061	__ / __ / __	(days or hours) Closing delinquency timer (System A) If address 090 key [3] OFF = address 061 in days (see page 10) If address 090 key [3] ON = address 061 in hours (see page 10)	Disabled

Figure 2: Decimal Display For LED Keypads

Each key in the first 2 rows of the keypad represents a specific value when the key is lit, as shown below left. When the key isn't lit, the key represents 0. Add the values of the lit keys to obtain the entered data value as shown in the example below right.



Example:



Note: LCD keypads will display current data on the screen.

Feature Select Programming

Addresses **062** to **126** are programmed using the Feature Select Programming method. In this method, every key on the keypad in each address represents an option or feature. Pressing a key will display it on the keypad and pressing it again will extinguish the key. The ON or OFF status of each key determines the selected feature. Addresses **080** to **085** are reserved for future use. To program using the Feature Select Programming method:

Table 6: Feature Select Programming Method

1. Press **[ENTER]** + **[INSTALLER CODE]** (default - EX10: **282828**; EX18: **383838**)
2. The **[ENTER]** key will flash to indicate you are in programming mode (LED keypad only).
3. Enter 3-digit **[ADDRESS]** (**062** to **126**).
4. After entering the address, the keypad will display the feature selection status. Turn the keys ON or OFF by pressing the appropriate key until the desired options are set. Press the **[ENTER]** key to accept, there will be a confirmation beep indicating the options have been accepted. The **[ENTER]** key will flash to indicate that the software is awaiting the next address entry.
5. Return to step 3 to continue programming or press **[CLEAR]** to exit programming mode.

Table 7: Code Priority For System "A" / STAY

KEY SELECT:		[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[0]	[STAY]	[AWAY]/ [FORCE]	[BYP]	[MEM]	[TRBL]	[2ND]
	User #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
062		<input type="checkbox"/>															
	User #:	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
064		<input type="checkbox"/>															
	User #:	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
066:		<input type="checkbox"/>															

Table 8: Code Priority For System "B" / AWAY / FORCE

KEY SELECT:		[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[0]	[STAY]	[AWAY]/ [FORCE]	[BYP]	[MEM]	[TRBL]	[2ND]
	User #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
068:		<input type="checkbox"/>															
	User #:	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
070:		<input type="checkbox"/>															
	User #:	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
072:		<input type="checkbox"/>															

Table 9: Code Priority for Codes with Bypass Access

KEY SELECT:		[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[0]	[STAY]	[AWAY]/ [FORCE]	[BYP]	[MEM]	[TRBL]	[2ND]
	User #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
074:		<input type="checkbox"/>															
	User #:	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
076:		<input type="checkbox"/>															
	User #:	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
078:		<input type="checkbox"/>															

△ = default

086:

See "TLM" table at right

Keypad = Regular arm

Keypad arming

Call back

Auto arm on time

Auto arm on no movement

Pulse dialing

Partitioning

Silent zone/panic generates a silent alarm

(1:2) Pulse Europe

See "Reporting Options" table at right

2-wire smoke detector (input 3)

Bell squawk on arm/disarm

Auto zone shutdown

KEY

OFF / ON

△	[2ND]	<input type="checkbox"/>
△	[1]	<input type="checkbox"/>

Stay arm / System A

△ [2] Enabled

△ [3] Enabled

△ [4] Enabled

△ [5] Enabled

△ [6] Enabled

△ [7] Tone dialing (DTMF)

△ [8] Enabled

△ [9] Generates only a report

△ [0] (1:1.5) Pulse USA

△ [STAY]

△ [AWAY]/

[FORCE]

△ [BYP] Enabled

△ [MEM] Enabled

△ [TRBL] Enabled

Telephone Line Monitoring (TLM)

KEY

[2ND] [1]

OFF OFF - TLM disabled

OFF ON - TLM generates trouble only

ON OFF - Generates an alarm if armed

ON ON - Silent alarm becomes audible

→ (address 086, key [9] has to be OFF)

Reporting Options

KEY

[STAY] [AWAY]/[FORCE]

OFF OFF - Reporting disabled

OFF ON - Regular reporting

ON OFF - Split* reporting (Alarms & System)

ON ON - Double reporting

Report Dialing Sequence (tel. no.)

Regular: 1,2,1,2,1,2,1,2, fail to comm.

Split*: Alarms - 1,1,1,1,1,1,1, fail to comm

System - 2,2,2,2,2,2,2, fail to comm

Double: 1,1,1,1,1,1,1, fail to comm

2,2,2,2,2,2,2, fail to comm

* On alarm, all reports are made to Tel. #1 until system is disarmed. Once disarmed, system reports are made to Tel. #2.

088:

Automatic event buffer transmission

Panic 1 (keys [1] and [3])

Panic 2 (keys [4] and [6])

Panic 3 (keys [7] and [9])

Panic 1 silent

Panic 2 silent

Panic 3 silent

Key [0]/[ARM] - Regular arming

Key [STAY] - Stay or system A arm

6-digit access codes

Tamper Recognition

Beep on exit delay

Report zone restore on bell cut-off

Zones with EOL (1kΩ)

Always report disarm

KEY

OFF / ON

△ [2ND] Enabled

△ [1] Enabled

△ [2] Enabled

△ [3] Enabled

△ [4] Audible

△ [5] Audible

△ [6] Fire

△ [7] Enabled

△ [8] Enabled

△ [9] 4-digit access codes

△ [0]

△ [STAY]

△ [AWAY]/ Enabled

△ [FORCE]

△ [BYP] On zone closure

△ [MEM] No EOL

△ [TRBL] Only after alarm

Tamper / Wire Fault Definitions

KEY

[0] [STAY]

OFF OFF - System Disarmed*

System Armed

Alarm as per

individual zone

definitions

OFF ON - No alarm. Trouble

code reported

ON OFF - Silent alarm.

Trouble & alarm

codes reported

ON ON - Audible alarm.

Trouble & alarm

codes reported**

Always generate

trouble and

alarm, audible or

silent as per

individual zone

definitions

OFF ON -

OFF OFF -

ON ON -

ON OFF -

ON ON -</p

Table 10: Zone Definition

Address	KEY SELECT:	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[0]	[STAY]	[FORCE] / [AWAY]	[1]	[2]	[3]	[4]	[5]	[6]	
	Zone:	1	2	3	4	5	6	7	8	9	10	11	12		13	14	15	16	17	18
092:	Intellizone = ON	092:	<input type="checkbox"/>	094:	<input type="checkbox"/>															
	Zone:	1	2	3	4	5	6	7	8	9	10	11	12		13	14	15	16	17	18
096:	Silent = ON	096:	<input type="checkbox"/>	098:	<input type="checkbox"/>															
	Zone:	1	2	3*	4	5	6	7	8	9	10	11	12		13	14	15	16	17	18
100:	24Hr./Fire = ON	100:	<input type="checkbox"/>	102:	<input type="checkbox"/>															
 Keypad zones cannot be set as 24Hr zones.		*When zone 3 is defined as 24Hr, it becomes a 4-wire smoke detector fire zone (2-wire smoke detector support must be disabled, address 086 key [BYP] = OFF). If using 2-wire smoke detectors and ATZ is enabled, zone 3 can be defined as 24Hr (EX10 only).																		
	Zone:	1	2	3	4	5	6	7	8	9	10	11	12		13	14	15	16	17	18
104:	Instant = ON	104:	<input type="checkbox"/>	106:	<input type="checkbox"/>															
	Zone:	1	2	3	4	5	6	7	8	9	10	11	12		13	14	15	16	17	18
108:	Follow = ON	108:	<input type="checkbox"/>	110:	<input type="checkbox"/>															
	Zone:	1	2	3	4	5	6	7	8	9	10	11	12		13	14	15	16	17	18
112:	Delay 2 = ON	112:	<input type="checkbox"/>	114:	<input type="checkbox"/>															
	SYSTEM A / STAY (if ON, zone is armed on Stay or "System A" arming)																			
	Zone:	1	2	3	4	5	6	7	8	9	10	11	12		13	14	15	16	17	18
116:	116:	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	118:	<input type="checkbox"/>					
	SYSTEM B (if ON, zone is armed in "System B" arming)																			
	Zone:	1	2	3	4	5	6	7	8	9	10	11	12		13	14	15	16	17	18
120:	120:	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	122:	<input type="checkbox"/>					
	Zone:	1	2	3	4	5	6	7	8	9	10	11	12		13	14	15	16	17	18
124:	Bypass = ON	124:	<input type="checkbox"/>	126:	<input type="checkbox"/>															
 Fire zones cannot be bypassed.																				

 **Do not use the Intellizone feature and an entry delay for the same zone, otherwise an alarm may occur as a user tries to disarm the system. Zones that are not selected at addresses 100 to 112 (EX10) or 114 (EX18) become "Delay 1" zones.**

Key Access Programming

Programs features quickly, without entering addresses or sections numbers. To activate Key Access Programming, press [ENTER] followed by the Installer code, Master code or User code 1 (code required depends on the desired feature; see below). Press the key corresponding to the desired feature. Press [ENTER] or [CLEAR] to exit. When communicating with Espload, it is impossible to enter programming mode.

Table 11: Key Access Programming

Key	Feature	Codes that can access feature
[8]	Installer Test Mode	Installer Code Only
	In Installer Test mode, a confirmation beep (intermittent) indicates that the test mode is enabled. A rejection beep indicates that the test mode is disabled. The bell will squawk during walk testing to indicate opened, functional zones.	
[9]	"Auto Arming" Time Program	Installer Code, Master Code or User Code 1
	Key [9] flashes. Enter 2-digit hour (00 to 23) and 2-digit minutes (00 to 59).	
[MEM]	Panel Time Programming	Installer Code, Master Code or User Code 1
	[MEM] key flashes. Enter 2-digit hour (00 to 23) and 2-digit minutes (00 to 59).	
[BYP]	Test Report	Installer Code, Master Code or User Code 1
	Reporting is enabled at address 086, keys [STAY] and [AWAY]/[FORCE] (see page 10). A value must be entered at address 512 (page 7) and both telephone and account numbers must be programmed.	
[TRBL]	Call Espload Via Telephone	Installer Code, Master Code or User Code 1
	Panel identifier and PC password (addresses 004 to 007 on page 3) and computer telephone number (addresses 008 to 015 on page 3) must be programmed.	
[AWAY]	Answer Espload	Installer Code, Master Code or User Code 1
	This feature is available when using the ADP-1 adapter. In Espload, "blind dial" must be activated in the "modem setup" section and panel phone number programmed.	
[STAY]	Cancel Communication Attempts	Master Code/User Code 1 only cancel calls to Espload The Installer Code can cancel all communications
	Until next reportable event.	

Connection Diagrams

The system hardware will recognize the following zone conditions:

Single Zone Connections

Figure 3: N.C. Contacts, without EOL Resistor




Figure 4: N.C. Contacts, with EOL Resistor (UL/cUL)




Figure 5: N.O. Contacts, with EOL Resistor (UL/cUL)




Figure 6: N.C. Contacts, without EOL Resistor, with Tamper Recognition





Figure 7: N.C. Contacts, with EOL resistor, with Tamper and Wire Fault Recognition (UL/cUL)



Advanced Technology Zone (ATZ) Connections

Figure 8: N.C. Contacts, without EOL Resistor




Figure 9: N.C. Contacts, without EOL Resistor, with Tamper Recognition




Figure 10: N.C. Contacts, with EOL Resistor, with Tamper and Wire Fault Recognition (UL/cUL)





Figure 11: Parallel Wiring



Other Connection Diagrams

Figure 12: Connecting Keypad Zone(s)




Figure 13: LED Keypad Anti-tamper Switch Connection

NOTE: To connect the keypad's tamper switch, simply connect the keypad as shown below. If the cover is removed when the system is armed, the keypad will send a zone open and the control panel will generate an alarm.




Figure 14: PGM Output Relay




Figure 15: Ground Start Circuit




Figure 16: 4-Wire Smoke Detector Connections (Fire Zone)




Figure 17: 4-Wire Smoke Detector Fire Reset

To program the PGM to conduct a 30 second smoke detector reset when [CLEAR] and [ENTER] are pressed simultaneously:

Address 039 = [BYP] (first digit) Address 042 = [2ND] [6]
Address 040 = [5] [0] Address 056 = [0] [3] [0]






Figure 18: 2-Wire Smoke Detector Connections (Fire Zone)




It is recommended that the smoke detectors be connected using a daisy chain configuration.

EX10 Wiring Diagram




Inset 1: Zone Recognition for the EX10 with ATZ Enabled (serial)


Control Panel Terminals



Inset 2: Connecting the Bell/Siren



EX18 Wiring Diagram




Power Down Reset

Performing a power down reset will set the Installer and Master codes to factory default. Values entered at addresses **008** to **043**, **062** to **124**, **300** to **527** and all user codes will be set to factory defaults. Programmed values at addresses **003** to **007** do not change. To perform a reset, the installer lock must be disabled. To perform a power down reset perform the following:

1. Verify installer lock is disabled.
2. Remove the battery and AC power from the control panel.
3. Remove all connected wires and devices from the PGM (PGM1 for EX18) and zone 1 terminals.
4. Short the PGM (PGM1 for EX18) and zone 1 terminals with a wire.
5. Reconnect the AC and battery power to the control panel.
6. Wait for 10 seconds and remove the wire.

Figure 19: Power Down Reset for EX10 or EX18



Warranty

Paradox Security Systems Ltd. ("Seller") warrants its products to be free from defects in materials and workmanship under normal use for a period of one year. Except as specifically stated herein, all express or implied warranties whatsoever, statutory or otherwise, including without limitation, any implied warranty of merchantability and fitness for a particular purpose, are expressly excluded. Because Seller does not install or connect the products and because the products may be used in conjunction with products not manufactured by Seller, Seller cannot guarantee the performance of the security system and shall not be responsible for circumstances resulting from the product's inability to operate. Seller obligation and liability under this warranty is expressly limited to repairing or replacing, at Seller's option, any product not meeting the specifications. Returns must include proof of purchase and be within the warranty period. In no event shall the Seller be liable to the buyer or any other person for any loss or damages whether direct or indirect or consequential or incidental, including without limitation, any damages for lost profits stolen goods, or claims by any other party, caused by defective goods or otherwise arising from the improper, incorrect or otherwise faulty installation or use of the merchandise sold.

Notwithstanding the preceding paragraph, the Seller's maximum liability will be strictly limited to the purchase price of the defective product. Your use of this product signifies your acceptance of this warranty.

BEWARE: Dealers, installers and/or others selling the product are not authorized to modify this warranty or make additional warranties that are binding on the Seller.

© All rights reserved. Specifications may change without prior notice.

Notes

