

## . Safety Information

1. This is a Class 2 laser tool, laser radiation is emitted from this product and is manufactured to comply IEC 60825-1:2007, EN 60825-1:2007, EN 61326-1:2013 and CRF21, parts 1040.10 and 1040.11.
2. Use of controls, adjustment procedures other than those specified herein may result in laser radiation exposure.
3. Never stare directly into beam or aim the laser beams at others.
4. Product contains semiconductor laser diodes with wavelengths of 650 nanometers.
5. The total continuous output of the beams never exceeds 1.0 milli-watts.
6. Product complies with EMC Test according to EN61000-6-3:2001+A11:2004, EN61000-6-1:2001, EN61326-1:2013, IEC 61326:2012 and FCC Test according to PART 15.
7. For devices support Bluetooth are complied with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



FCC ID: YWSLB11310000001  
IC ID: 20299-LB113100001



1

## . Contents

· Inside The Box ----- 2	· Measuring Functions ----- 6
· Specification	Area Measurement
· Overview for CX100 ----- 3	Volume Measurement
· Overview for Screen	Indirect Measure (Pythagorean) I, II, III
· Battery Installation & Power Status ----- 4	Indirect Measure (Angle Sensor) IV, V, VI
· Switch On and Off	· Stake-Out Measurement ----- 7
· Distance Measurement	Setup Stake-Out Distance
· Measurement Reference ----- 5	Use of Stake-Out with preset Distance
· Measurement Addition & Subtraction	· Store Measurement to Memory and Lookup ----- 8
· Unit Setting	· Countdown Measure
· Backlight & Laser Pointer Mode	· iM <sup>2</sup> app & Bluetooth Setup ----- 9
	· Calibration of Angle Sensor ----- 10

## . Inside The Box

- CX100 Laser Distance Meter x1
- AAA Battery x2
- Operation Manual x1
- Carrying Case x1
- Safety Strap x1

## . Specification

· Measuring Range	0.05m- 100m
· Resolution	0.001m
· Accuracy	±1.5mm
· Measuring Speed	0.5sec
· Laser Type	650nm, Class II, <1mW
· Beam Size	25mm@15m
· Battery	AAA Battery x2, Up to 10,000 measures
· Dimension	116 x48 x31mm
· Operation Temperature	-5°C~40°C
· Storage Temperature	-20°C~60°C
· Automatic Power-Off	-Laser 30 Seconds -Device 180 Seconds

2

## . Error Code

Code	Description	Solution
Err01	Out of measuring range	Measuring in a proper range
Err02	Reflected signal is too weak	Select a better surface
Err03	Out of display range (Max Value: 999999), e.g: result of area or dimension is out of display range.	Divide calculation into intermediate steps
Err04	Pythagorean calculation error	Check and verify values and steps are correct
Err05	Low Battery	Install a new battery
Err06	Out of working temperature	Measure in an environment within specified working temperature
Err07	Ambient light is too strong	Measure in a darker place (shadow target)

## . Service Support

Please contact your local dealer or contact us through service email : [ reps@precaster.com.tw ] for further assistance.


CX100 Operation Manual

www.precaster.com.tw


Precaster Enterprises CO., LTD.

Made in Taiwan

## . Overview for CX100



## . Overview for Screen



3

# LASER DISTANCE METER CX100 Operation Manual




AAA x2  
Batteries

CX100 Operation Manual

www.precaster.com.tw


## . Battery Installation & Power Status

1. This unit is powered by 2 x AAA Batteries.
2. Remove battery lid and observing correct polarity before install batteries.
3. Battery level is showed on screen with batty icon on screen .
4. When the icon appears, there are approximately 1000 times to measure.
5. Replace batteries when low battery icon flash on screen.
6. To change new batteries, when install new batteries, then close back lid.



## . Switch On and Off

1. Be sure to check battery status before start.
2. Click the or to turn on the device.
3. The device will process the initial procedure and get ready to measure by turn on the laser dot.
4. Tap and hold for 2 seconds to turn off.
5. The device will turn off automatically after 180 seconds.



## . Distance Measurement

### Single Measurement Mode

1. Move the laser dot onto the target.
2. Keep your position stable and click .
3. The measurement will be displayed on LCD Screen and laser will be turn off.
4. Click again to enable the laser dot for next measurement.



### Continuous Measurement Mode

1. Continuous Measurement is also called tracking measurement and is recommend to use for seeking proper distance.
2. Move the laser dot onto the target.
3. Keep your position stable and tap and hold , the laser distance meter will enter continuous measurement mode.
4. Move the device back and forward to proper distance.
5. Click to pause the measurement.
6. Click again to leave the continuously measurement mode.

4

**. Measurement Reference**

1. There are four reference positions for measurement . They are back of the unit, front of the unit, tripod thread and the spike
2. Click to select the proper position.

**. Measurement Addition & Subtraction**

1. To make summary or difference between two measurements is easy
2. Finish your first measurement, then click to save as Addend or to save as Minuend.
3. Take the second measurement, then click to add from addend or to subtract minuend.

**. Unit Setting**

1. There are 8 units inside the laser distance meter.
2. Click and hold to select preferred unit.
3. Unit Switch Reference

	meter	feet	inch	0'0"1/32	inch	inch	inch	尺
<b>Length</b>	m	ft	in	0'0"1/32	1/32in	1/16in	1/8in	10/33
<b>Area</b>	m <sup>2</sup>	ft <sup>2</sup>	ft <sup>2</sup>	ft <sup>2</sup>	ft <sup>2</sup>	ft <sup>2</sup>	ft <sup>2</sup>	P
<b>Volume</b>	m <sup>3</sup>	ft <sup>3</sup>	ft <sup>3</sup>	ft <sup>3</sup>	ft <sup>3</sup>	ft <sup>3</sup>	ft <sup>3</sup>	m <sup>3</sup>

**. Backlight & Laser Pointer Mode**

1. Click and hold to turn on or off the backlight.
  2. To enable Laser Pointer Mode, click and hold .
- The laser indicator will display continuously until the mode is turned off.

**. Store Measurement to Memory and Lookup**

1. When you want to add the measurements on the screen, press to add to memory. You could find the location in memory on the top of screen.
2. To lookup stored measurements, press and hold to enter the lookup mode.
3. Press to move the index up and Press to move index down.
4. To clear all stored measurements, press and hold again in lookup mode to clear all memory.

**. Countdown Measure**


1. For a more stable measurement or you could use countdown measure function to trigger measuring in setting times.
2. Click to set your preferred self-trigger time.
3. Timer could set from 3 seconds to 15 seconds.
4. After the time is set, press to activate measuring.
5. After a beep, the measured result appears on main screen.



**. Measuring Functions**

**Area Measurement**

1. Click to enable Area measurement.
2. Laser will be activated when entering area measurement mode.
3. Follow the instructions on main screen to measure WIDTH and LENGTH.
4. After finish all the instructions, the result [AREA] will be showed on screen.




**2. Volume Measurement**

1. Click twice to enable Volume measurement.
2. Laser will be activated when entering volume measurement mode.
3. Follow the instructions on main screen to measure WIDTH, LENGTH and HEIGHT.
4. After finish all the instructions, the result [VOLUME] will be showed on screen.

**3. Indirectly Height I, II & III Measurement (base on Pythagorean)**

1. Click thrice, four and five times to enable Indirectly Measurement.
2. Laser will be activated when entering indirectly measurement mode.
3. Follow the instructions on main screen to measure the LENGTH OF HYPOTENUSE(S) and BASE.
4. After finish all the instructions, the result [HEIGHT] will be showed on screen.



**4. Indirectly Height IV, V & VI Measurement (base on Angle Sensor)**


1. Click six, seven and eight times to enable Indirectly Measurement.
2. Laser will be activated when entering indirectly measurement mode.
3. The angle degree will be displayed on top of screen.
4. Indirectly Height Measurement IV is design to get height by measuring Length Hypotenuse.
  - Tilt the device to proper angle than press measure to measure the length of hypotenuse
  - The angel will be fixed and length and high will be display on the screen also.
5. Indirectly Height Measurement V is design to get full height by measuring two length of hypotenuse.

**. iM<sup>2</sup> app & Bluetooth Setup**


For the model supported Bluetooth could connected with phones support BLE4.0, For Bluetooth version on your phone, please contact with your phone manufacturer. We currently offer Measurement Kit on iTunes and Play Store.



1. To turn on Bluetooth in pairing mode, press and hold .
2. The Bluetooth icon will keep flashing during paring.
3. Select proper device in the Connection Manager of APP
4. After connected with a beep sound the icon will stop flashing.



- Tilt the device to proper angle than press measure to measure the first and second length of hypotenuse
  - The angel will be fixed and length and high will be display on the screen also.
6. Indirectly Height Measurement VI is design to get difference between heights by measuring two length of hypotenuse.
    - Tilt the device to proper angle than press measure to measure the first and second length of hypotenuse
    - The angel will be fixed and length and high difference will be display on the screen also.




**4. Stake-Out Measurement**

Stack out measurement help users to split a long distance into several piece equally. The function need to be used in Continuous Measurement Mode with preset distance.

**Setup Stake-out distance:**

1. Click six time to enter setup of stak-out distance.
2. Click to increase the value.
3. Click to decrease your value.
4. Click to shift between numbers.
5. Click to save the value and exit the setup mode.
6. Click to restore zero.



**Use of Stake-Out with Preset Distance**

1. Enable "Continuous Mode" by tap and hold .
2. Forward and backward arrow will be showed next to the measurements.
3. Follow the arrow to desired distance, Device beeps to notify you when reach the preset distance and its multiplies.

**. Calibration of angle sensor**

1. Find a leveled and flat surface, such as table before start calibration.
2. Turn the device off.
3. Tap and hold function key and turn the device on to enter calibration mode [CAL0]
4. You could press Clear button to restore to default.
5. Or put the device straightly and make the LCD face to you to start calibration.
6. Press measure key to start self-calibration (1st step) [CAL1]
7. The short beep is notification for getting ready to start.
8. The long beep is notification for calibration finished, than turn the device 180 degree straightly
9. Press measure key to continue calibration procedure (2nd step) [CAL2].
10. When the step 2 is done, lay the device down on the table.
11. Press measure key to continue calibration procedure (3rd step) [CAL3].
12. When the step 3 is done, turn the device 180 degree.
13. Press measure key to continue calibration procedure (4th step) [CAL4].
14. After calibration, the device will be turned off automatically.

