# LINI-T

# UT60A **Operating Manual**



## Modern Digital Multimeter

#### Overview

This Operating Manual covers information on safety and cautions Please read the relevant information carefully and observe all the Warnings and Notes strictly.

# A Warning

To avoid electric shock or personal injury, read the "Safety mation" carefully before using the Meter

Digital Multimeter UT60A (hereafter referred to as "the Meter") is a stable, reliable and safe 4000-count multimeter designed with large-scale integrated circuits and integral A/D converter as the core, overload protection for all ranges and unique structure. The Meter can measure AC&DC voltage, AC&DC current, resist -ance, diode, continuity, capacitance, frequency/duty cycle. The double-moulded casing design gives it a perfect insulation, which altogether makes the Meter a ideal solution for your needs.

#### Unpacking Inspection

Open the package case and take out the Meter. Check the following items carefully for any missing or damaged part:

Item	Description	Qty
1	Operating Manual	1 pc
2	Test Leads	1 pair
3	9V Battery (NEDA1604, 6F22 or 006P)	1 pc
	(installed)	
4	RS232C Interface Cable	1 pc
5	CD-ROM (Installation Guide & Computer	1 pc
	Interface Software)	

In the event you find any missing or damaged item, please contact • The Meter is suitable for indoor use. your dealer immediatel

#### Safety Information

This Meter complies with IEC 61010 Overvoltage Category (CAT. III 1000V, CAT.IV600V), Pollution Degree 2 and Double Insulation standards.

CAT. III: Distribution level, fixed installation, with smaller transient overvoltages than CAT. IV CAT IV:Primary supply level, overhead lines, cable systems etc.

Use the Meter only as specified in this operating manual,otherwise the protection provided by the Meter may beimpaired.

In this manual, a Warning identifies conditions and actions that pose hazards to the user, or may damage the Meter or the equip -ment under test. A Note identifies the information that user should pay attention to.

# **A** Warning

To avoid possible electric shock or personal injury, and to avoid possible damage to the Meter or to the equipment under test, adhere to the following rules:

- Before using the Meter inspect the case. Do not use the Meter if it is damaged or the case (or part of the case) is removed. Look for cracks or missing plastic. Pay atte -ntion to the insulation around the connectors.
- Inspect the test leads for damaged insulation or exposed metal. Check the test leads for continuity. Replace damaged test leads with identical model number or elec -trical specifications before using the Meter.
- Do not apply more than the rated voltage, as marked on the Meter, between the terminals or between any terminal The rotary switch should be placed in the right position
- and no any changeover of range shall be made during measurement to prevent damage of the Meter.
- Please take extra caution when working at an effective voltage over 60V in DC or 30V rms in AC for there is danger of electric shock

- Use the proper terminals, function, and range for your
- Do not use or store the Meter in an environment of high temperature, humidity, explosive, inflammable and strong magnetic field. The performance of the Meter may deterio rate after dampen
- When using the test leads, keep your fingers behind the finger guards.
- Disconnect circuit power and discharge all high-voltage capacitors before testing continuity, diodes, resistance, capacitance or current.
- Before measuring current, check the Meter's fuses and turn off power to the circuit before connecting the Meter to the circuit.
- Replace the battery as soon as the battery indicator appears. With a low battery, the Meter might produce false readings that can lead to electric shock and personal injury.
- Remove test leads and RS232C interface cable from the Meter and turn the Meter power off before opening the Meter case.
- When servicing the Meter, use only the replacement parts with the same model or identical electrical specifications. • The internal circuit of the Meter shall not be altered at
- will to avoid damage of the Meter and any accident. • Soft cloth and mild detergent should be used to clean the surface of the Meter when servicing. No abrasive and solvent should be used to prevent the surface of the Meter

from corrosion, damage and accident

• Under the environment with high (+/-4kV) electrostatic discharge, the Meter may not be operated as normal The user may require resetting the Meter. conditio • Turn the Meter off when it is not in use and take out the

- battery when not using for a long time. Constantly check the battery as it may leak when it has been
- using for some time, replace the battery as soon as leaking appears. A leaking battery will damage the Meter.

#### International Electrical Symbols

~	AC (Alternating Current).
	DC (Direct Current).
ม	AC or DC.
÷	Grounding.
	Double Insulated.
Ļ	Low Battery Indication.
•1))	Continuity Test.
∔	Diode.
Ŧ	Capacitance Test.
Щ	Fuse.
$\mathbb{N}$	Warning. Refer to the Operating Manual.
CE	Conforms to Standards of European Union.

<ul> <li>Policitorial buttoris</li> <li>Potary Switch</li> <li>HzVΩ Input Terminal: Input for voltage, frequency/duty cycle, resistance, diode, continuity and capacitance measurements.</li> <li>COM Input Terminal: Input for 0.1µA to 400.0mA current measurements.</li> <li>10A Input Terminal: Input for 0.001A to 10.00A current measurements</li> <li>Rotary Switch</li> </ul>					
tary switch	ow offers information about positions around the	•			
Rotary Switch Function Position					
Hz V	DC voltage measurement range from 400.0mV to 1000V or AC voltage measurement range from 4.000V to 750.0V.				
$ \begin{array}{c} \bullet \bullet$					
⊣⊢	H Capacitance test range from 40.00nF to 100.0μF.				
Hz% Frequency measurement range from 10.00Hz to 10.00MHz. Duty Cycle measurement.					
μA₩	AC or DC current measurement				
Hz mA <del>~</del>	range from 400.0 µA to 4000µA				
Hz	range from 40.00mA to 400.0mA.				
Hz≂	AC or DC current measurement				
A range from 4.000A to 10.00A.					

The Meter Structure (See Figure 1)

① LCD Display

ro

Functional Buttons

**Functional Buttons** e table below offers outton operations

Button	Measuring	Operation Performed		
POWER	Function Any rotary switch position	Turn the power on and off.		
(BLUE)	Hz V	Switches between AC, DC voltage; the Meter beeps. DC is default.		
	•າ))→⊢ Ω	Switches between continuity, diode and resistance measurements; the Meter beeps. Resistance is default.		
	μA Ηz	Switches between AC and DC current range from 400.0 µA to 4000 µA; the Meter beeps. DC is default.		
	mAIX Hz	Switches between AC and DC current range from 40.00mA to 400.0mA; the Meter beeps. DC is default.		
	Hz A	Switches between AC and DC current range from 4.000A to 10.00A; the Meter beeps. DC is default.		
RANGE	Any rotary switch position except at <b>Hz%</b> and <b>-1(-</b> mode.	<ol> <li>Press RANGE to enter the manual ranging mode; the Meter beeps. Manually selecting a range causes the Meter to exit the Hold and REL modes.</li> <li>Press RANGE to step through the ranges available for the selected function; the Meter beeps.</li> <li>Press and hold RANGE for around 2 seconds to return to autoranging; the Meter beeps.</li> </ol>		
Hz %	Hz%	<ol> <li>Press Hz % to start the frequency counter; the Meter beeps.</li> </ol>		

Нz % Нz %		<ul> <li>enter duty cycle mode; the Meter beeps.</li> <li>3. Press Hz % again to return to the frequency counter mode; the Meter beeps.</li> <li>1. Press to start the frequency counter; the Meter beeps.</li> <li>2. Press again to enter</li> </ul>		
	mA⊼ Hz or Hz⊼ A	Meter beeps. 3. Press the third time to return to voltage or current measurement mode; the Meter beeps.		
REL	Any rotary switch positic excep Hz%	in any measuring mode except in frequency/duty t cycle mode; the Meter		
HOLD	Any rotary switch positio	Press <b>HOLDH</b> to enter and exit the Hold mode in any mode, the		
	Symbols	(See Figure 2) 5 6 ⑦ → → → → √ 8		
(5) 1 				
Figure 2				
Number ①	Symbol AC	Meaning Indicator for AC voltage or current. The displayed value is the mean value.		
2	Αυτο	The Meter is in the auto range mode in which the Meter automatically selects the range with the best resolution.		
3	RS232C	Data output. It is always on the LCD, but data output is only in progress when the Meter is connected to the computer via the included		
		data output is only in progress when the Meter is connected to the		
4	%	data output is only in progress when the Meter is connected to the computer via the included		
4	Ξ	data output is only in progress when the Meter is connected to the computer via the included RS232C Interface Cable. Percent: Used for duty cycle measurements. Data hold is active.		
6		data output is only in progress when the Meter is connected to the computer via the included RS232C Interface Cable. Percent: Used for duty cycle measurements. Data hold is active. The REL mode on, which display the present value relative to the stored value.		
5 6 7		data output is only in progress when the Meter is connected to the computer via the included RS232C Interface Cable. Percent: Used for duty cycle measurements. Data hold is active. The REL mode on, which display the present value relative to the stored value. The battery is low. ▲ Warning: To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator appears.		
6		data output is only in progress when the Meter is connected to the computer via the included RS232C Interface Cable. Percent: Used for duty cycle measurements. Data hold is active. The REL mode on, which display the present value relative to the stored value. The battery is low. <b>∆</b> Warning: To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the		

Hz, kHz, MHz

MΩ: Megaohm. 1 x 10<sup>6</sup> or

capacitance. uF: Microfarad, 1 x 10<sup>-6</sup> or

0.000001 farads. nF: Nanofarad. 1 x 10° or

0.000000001 farads.

Hertz. The unit of

frequency in

cycles/second.

kHz: Kilohertz. 1 x 103 or 1,000 hertz.

MHz: Megahertz. 1 x 10<sup>6</sup> or

1,000,000 hertz.


1.000.000 ohms. F, µF, nF F: Farad. The unit of

	V, mV	V: Volt volt mV: Mill 0.00
	Α, mA, μΑ	A: Am unit mA: Mill μA: Mic 0.0
15		Indicate
16	OL	The inpu

# **Measurement Operation** A. Measuring AC & DC Voltage

A Warning To avoid harm to you or damage to the Meter from electric shock, please do not attempt to measure voltages higher than 1000V / 750V rms although readings may be obtained.

AC Voltage Measurement (See Figure 3)



The AC voltage ranges are:4.000V, 40.00V, 400.0V and 750.0V. To measure AC Voltage connect the Meter as follows: 1. Insert the red test leadinto the  $HzV\Omega$  terminal and the black test lead into the COM termina 2. Set the rotary switch to  $Hz \overline{\sim} V$  and press BLUE button to

select AC measurement mode 3 Connect the test leads across with the object being measured value of sine wave (mean value response).

to  $10 k \Omega$ , the error is negligible (0.1% or less).

circuit under test

DC Voltage Measurement (See Figure 4)



The DC Voltage ranges are: 400.0mV, 4.000V, 40.00V,400.0V test lead into the COM termi

- 2 Set the rotary switch to Hz = V. DC measurement is default resistance measurement (  $\Omega$  ) is default or press **BLUE** or press BLUE button to select DC measurement mode button to select  $\Omega$  measurement mode. 3. Connect the test leads across with the object being measured.
- The measured value shows on the display Note
- to  $10k\Omega$ , the error is negligible (0.1% or less). When DC voltage measurement has been completed, disconnect the connection between the testing leads and the circuit under test.
- B. Measuring Continuity. Diodes & Resistance / Warning

To avoid damage to the Meter or to the devices under test, disconnect circuit power and discharge all the high-voltage capacitors before measuring continuity, diodes & resistance

Testing for Continuity (See Figure 5)



л	14.000A to 10.00A.	
s nfe	ormation about the functio	nal
ום ח	Operation Performed	Nu

ts. The unit of tage. ivolt. 1 x 10<sup>-3</sup> or 01 volts. peres (amps). The tof current. It of current. lliamp.  $1 \times 10^{-3}$  or 001 amperes. croamp.  $1 \times 10^{-6}$  or 000001 amperes. s negative reading out value is too large for the selected range





Figure 3

- The measured value shows on the display, which is RMS
- In each range, the Meter has an input impedance of 10MΩ. This loading effect can cause measurement errors in high impe -dance circuits. If the circuit impedance is less than or equal
- When AC voltage measurement has been completed, disconnect the connection between the testing leads and the



- and 1000V. To measure DC voltage.connect the Meter as follows: 1. Insert the red test lead into the **HzV**  $\Omega$  terminal and the black
- In each range, the Meter has an input impedance of 10M  $\Omega.$ This loading effect can cause measurement errors in high impe
- -dance circuits. If the circuit impedance is less than or equal




- To test for continuity, connect the Meter as below:
- 1. Insert the red test lead into the  $HzV\Omega$  terminal and the black test lead into the COM terminal
- 2. Set the rotary switch to  $\bullet \bullet \bullet \to \Omega$  and press **BLUE** button to select •)) measurement mod
- 3. The buzzer sounds if the resistance of a circuit under test is less than 100 O

#### Note

- The LCD displays *OL* indicating the circuit being tested is open.
- When continuity testing has been completed, disconnect the connection between the testing lead and the circuit under test.

Testing Diodes (See Figure 6)




Use the diode test to check diodes, transistors, and other semicor -ductor devices. The diode test sends a current through the semiconductor junction, and then measures the voltage drop across the junction. A good silicon junction drops betw 0.5V and 0.8V.

- To test a diode out of a circuit, connect the Meter as follows: 1. Insert the red test lead into the  $\textbf{HzV}~\Omega$  terminal and the black
- test lead into the COM terminal 2. Set the rotary switch to  $-\eta \rightarrow \Omega$  and press **BLUE** button to
- select measurement mode.
- 3. For forward voltage drop readings on any semiconductor component, place the red test lead on the component's anode and place the black test lead on the component's cathode. The measured value shows on the display

Note

- In a circuit, a good diode should still produce a forward voltage drop reading of 0.5V to 0.8V; however, the reverse voltage drop reading can vary depending on the resistance of other path -ways between the probe tips.
- Connect the test leads to the proper terminals as said above to avoid error display
- The LCD will display *OL* indicating open-circuit or wrong
- The unit of diode is Volt (V), displaying the positive-connection voltage-drop value
- When diode testing has been completed, disconnect the conne -ction between the testing leads and the circuit under test.

Resistance Measurement (See Figure 7)



 $400.0\Omega$ , 4.000 kΩ, 40.00 kΩ, 400.0 kΩ, 4.000 MΩ and 40.00 MΩ


- 1. Insert the red test lead into the  $\text{HzV}\Omega\,$  terminal and the black test lead into the COM termina
- The measured value shows on the display.

- resistance measurement. To obtain precision reading in low-resistance measurement, that is the range of 400.0  $\Omega$ , short-circuit the input terminals beforehand, press **REL** $\Delta$  to eset to 0, then this shorted value will be automatically subtrac -ted from the subsequent measured readings.
- For high-resistance measurement (>1M $\Omega$ ), it normally takes several seconds to obtain a stable reading.
- If  $\Omega$  reading with shorted test leads is not  $\leq 0.5 \Omega$ , check for loose test leads, incorrect function selection, or enabled Data Hold function
- The LCD displays *OL* indicating open-circuit for the tested resistor or the resistor value is higher than the maximum range of the Meter.
- When resistance measurement has been completed, disconnect the connection between the testing leads and the circuit under
- C. C. Measuring Capacitance (See Figure 8)

#### A Warning

To avoid damage to the Meter or to the equipment under test, disconnect circuit power and discharge all high-voltage capacitors before measuring capacitance. Use the DC Voltage function to confirm that the capacitor

is discharged. Never attempt to input over 60V in DC or 30V rms in AC to avoid personal injury.



The resistance ranges are

To measure resistance connect the Meter as follows:

- 2. Set the rotary switch to ....)
- 3 Connect the test leads across with the object being measured.

• The test leads can add  $0.1 \Omega$  to  $0.2 \Omega$  of error to

### P/N·110401104306X



The Meter's capacitance ranges are: 40.00nF, 400.0nF, 4.000µF,  $40.00 \mu$  F, and  $100.0 \quad \mu$  F. To measure capacitance, connect the Meter as follows:


- 1 Insert the red test lead into the HzV Q terminal and the black test lead into the COM terminal
- 2. Set the rotary switch to ++.
- 3. Connect the test leads across with the object being measured. The measured value shows on the display.

# Note

• For testing the capacitor with polarity, connect the red test lead to anode & black test lead to cathode.

- To increase the accuracy of capacitance, measurement esp -ecially when measuring under 400nF, use REL mode to au -tomatically subtract the Meter built-in equalized capacitance and residual capacitance of test leads from the result.
- It takes a longer time when testing a high capacitor value, the testing time is around 15 seconds in  $100\mu$  F range. When capacitance measurement has been completed, disco
- -nnect the connection between the testing leads and the circuit under test.

D. Measuring Frequency & Duty Cycle (See Figure 9)



### Frequency Measurement

The measurement ranges are from 10Hz to 40MHz. To measure frequency, connect the Meter as follows:

- 1. Insert the red test lead into the HzV  $\Omega$  terminal and the black test lead into the COM terminal.
- 2. Set the rotary switch to Hz% ;frequency measurement (Hz) is default or press Hz% button to select Hz measurement mode
- 3. Connect the test leads across with the object being measured. The measured value shows on the display.

- To obtain a stable reading when measuring: Input amplitude > 30V rms & ≤1 kHz frequency signal: Set the rotary switch to Hz = V,  $\mu A = Hz$ , mA = Hz or Hz = A. Then press Hz% to select Hz measurement mode to obtain frequency value.

Input amplitude \$30V rms frequency signal: Follow the above step 2 to carry out the measurement.

• When making frequency measurement at voltage or current range, please refer to the following requirements

Range	Signal Requirement	Frequency Range
v ~	≥200mV	
μΑ ~	≥200 μA	10Hz~1kHz
mA ∼	≥20mA	
A~	≥2A	]

•When Hz measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

### **Duty Cycle Measurement**

The duty cycle measurement range is 0.1% ~ 99.9%.

To measure duty cycle:

- 1. Set up the Meter to measure frequency. 2. To select duty cycle, press Hz% button again until the
- % symbol is shown on the display.
- 3. Connect the test leads across with the object being measured.

The measured value shows on the display. Note

- The LCD displays 000.0% indicating the input signalis high or low level.
- When duty cycle measurement has been completed, disconnect the connection between the testing leads and the circuit under test

### E. Measuring DC/AC Current (See Figure 10)

A Warning

Never attempt an in-circuit current measurement where the open-circuit voltage between the circuit and ground is greater than 250V. If the fuse burns out during measurement, the Meter may be damaged or the operator himself may be hurt Use proper terminals, function, and range for the measurement

do not parallel them across any circuit 0000 µA≂Hz, mA≂Hz o Hz≂A.

When the testing leads are connected to the current terminals.

Figure 10 The current measurement has 3 measurement positions on the

#### rotary switch: $\mu A = Hz$ , mA = Hz and Hz = A.

The  $\mu A = Hz$  has a 400.0 $\mu$ A and 4000  $\mu$ A range, with auto

- ranging; the mA = Hz has a 40.00mA and 400.0mA range. with auto ranging: Hz = A position has a 4.000A and 10.00A range. with auto ranging.
- To measure current, do the following: 1. Turn off power to the circuit. Discharge all high-voltage capacitors.
- 2. Insert the red test lead into the µAmA or 10A or terminal and the black test lead into the COM terminal.
- Set the rotary switch to  $\mu A = Hz$ , mA = Hz or Hz = A. Use the 10A terminal and Hz ZA measurement position
- if the current value to be tested is unknown. The Meter defaults to DC current measurement mode. To toggle between DC and AC current measurement func
- -tion, press BLUE button. AC current is displayed as an mean value (calibrated against
- sine wave RMS value). Break the current path to be tested. Connect the red test lead to the more positive side of the break and the black test
- lead to the more negative side of the break 6. Turn on power to the circuit.
- The measured value shows on the display Note
- For safety sake, the measuring time for high current should be ≤10 seconds for each measurement and the interval time between 2 measurements should be greater than 15 minutes.
- When current measurement has been completed, disconnect the connection between the testing leads and the circuit under

#### The POWER button

This is a self-lock switch used to turn on or off the power of the

## The BLUE button

It is used to select the required measurement function when there is more than one function at one position of the rotary switch

#### The Use of Relative Value Mode

The REL mode applies to all measurement functions except in frequency/duty cycle measurement, the meter subtracts a stored value from the present value and displays the relative value (  $\Delta$  ) as the result.

- The definition is as follows:
- Relative value ( $\Lambda$ ) = present value stored value For instance, if the stored value is 20.0V and the present value is 22.0V, the reading would be 2.0V.

If a new measurement value is equal to the stored value then display 0.0V. To enter or exit REL mode:

- Use rotary switch to select the measurement function before selecting **REL**  $\Lambda$  If measurement functions change manually after **REL**  $\Delta$  is selected, the Meter exits the REL mode.
- Press REL Ato enter REL mode, autoranging turns off except under capacitance testing mode, and the present measurement range is locked and display the last measurement value
- as "0" as the stored value. • Press REL  $\Delta$  again or turn the rotary switch to reset the stored value and exit REL Mode

Pressing **HOLD**[H] in REL mode makes the Meter stop updating. Pressing HOLD[H] again to resume updating.

#### **Operation of Hold Mode**

A Warning

To avoid possibility of electric shock, do not use Hold mode to determine if circuits are without power. The Hold mode will not capture unstable or noisy readings.

- The Hold mode is applicable to all measurement functions. • Press HOLD H to enter Hold mode; the Meter beeps.
- Press **HOLD**[**H**] again or turn the rotary switch to exit Hold
- mode: the Meter beer In Hold mode, H is displayed.

# **General Specifications**

- Maximum Voltage between any Terminals :1000V rms. and Grounding
- A Fused Protection :0.5A, 250V fast type Glass for µ AmA Input

- 10A 250V fast type Glass fuse. \$ 5x20 mm. for 10A Input Terminal Maximum Display : 3999.
- : Updates 3 times /second. Measurement Speed Temperature: Operating :0<sup>°</sup>C~40<sup>°</sup>C (32<sup>°</sup>F ~104<sup>°</sup>F). -10 °C~50 °C(14 °F~122 °F). Storage Relative Humidity ·≤75% @ 0°C - 30°C

: One piece of 9V NEDA1604

D. Capacitance

40nE

40µF

10Hz~

10MHz

0.1%~

99.9%

(Duty cycle)

F. DC Current

4000<sup>µ</sup>A

40mA

400mA

4A

10A

Remark

Range

400 µA

4000u

40mA

400mA

4A

10A

Remarks:

• 4A & 10A Range:

15 minutes

Maintenance

⚠ Warning

400µA 0.1µA

Range Resoluti

400nF 100pF 4μF 1nF

100µF 100nF

10pF

10nF

E. Frequency & Duty Cycle

Range Resolution Accuracy

N/A

0.01%

Input sensitivity as follows: ≤1MHz: ≤300mV rms;

Range Resolution Accuracy

1µA

0.01mA

0.1mA

0.001A

0.01A

Resolutio

0.1μA 1μA

0.01mA

0.1mA

0.001A

0.01A

Frequency response : 40Hz ~ 400Hz

battery and fuse replacement instruction.

-mance test, and service information

and strong magnetic field.

B. Testing the Fuses

A Warning

To test the fuse

BLUE button.

-ent. Do not use abrasives or solven

moisture in the terminals can affect readings

identical amperage, voltage, and speed ratings

t tip to the 10A or µAmA terminal.

• If the Meter beeps, the fuse is good

water inside the case.

A. General Service

Displays RMS value of sine wave (mean value response).

interval time between 2 measurements greater than

This section provides basic maintenance information including

Do not attempt to repair or service your Meter unless you are

qualified to do so and have the relevant calibration, perfor

To avoid electrical shock or damage to the Meter, do not get

• Periodically wipe the case with a damp cloth and mild deterg

• To clean the terminals with cotton bar with detergent, as dirt or

• Press the **POWER** to turn off the Meter when it is not in use

• Do not store the Meter in a place of humidity, high temperature

To avoid electrical shock or personal injury, remove the test

leads and any input signals before replacing the battery or fuse.

To prevent damage or injury, install ONLY replacement fuses with

1. Set the rotary switch to  $\cdot \cdot \cdot D$  and select  $\cdot \cdot D$  by pressing

2. Plug a test lead into the terminal  $\,{\rm HzV}\,\Omega{\rm and}$  touch the probe

• If the display shows *OL*, replace the fuse and

and take out the battery when not using for a long time.

For continuous measurement ≤10 seconds and

4A & 10A Range:

15 minutes

G. AC Current

>1MHz: <600mV rms

Maximum input amplitude: 30V rms.

0.1%~99.9% Range: Reading is only for reference purpose.

Remarks: • 10Hz~10MHz Range:

Accuracy

+(3%+5)

+(4%+5)

+(0.1%+3)

N/A

+(1%+2)

- (1.2%+3

For continuous measurement ≤10 seconds and

interval time between 2 measurements greater than

Accuracy

+(1.5%+5)

±(2%+5)

- (2.5%+5)

Overload

Protectic

600Vp

Overload

Protectio

600Vp

Overload

ast type Glass

fuse, ø 5x20mm

fuse, ¢ 5x20mm

Overload

Protection

st type Glass

fast type Glass fuse, φ 5x20mm

0.5A. 250V

10A. 250V

10A, 250V,

± (1.5%+5) fast type Glass

0.5A. 250V

- ≤50% @ 31°C- 40°C. Altitude:Operating : 2000 m ; Storage: 10000 m.
- Battery Type

- or 6F22 or 006P. Low Battery Indication · Display 🖡
- Display Data Hold
- Negative reading : Display
- : Display **0L**. Overloading Equipped with full icons display.
- Auto and manual range selectable
- Dimensions (HxWxL) · 177 x 85 x 40 mm : Approximate 300g (battery Weight included).
- : IEC61010 CAT.III 1000V, Safety/Compliances CAT.IV 600V overvoltage and double insulation standard.

:CE UL & CUL

# Accuracy Specifications

Certification

Accuracy: ±(a% reading + b digits) guarantee for 1 year Operating temperature: 23°C ±5°C. Relative humidity: <75%.

# Temperature coefficient: 0.1 x (specified accuracy) / 1°C.

A. AC Voltage					
Range	Resolution	Accuracy	Overload Protection		
4V	1mV				
40V	10mV	土(1%+5)	1000V DC		
400V	100mV		750V AC rms continuous.		
750V	1V	±(1.2%+5)			

- Remarks:
- Input impedance  $\geq 10M \Omega$ • Displays RMS value of sine wave (mean value
- response)
- Frequency response: 40Hz ~ 400Hz.

Remarks:

Diode Range:

reading 0.5V~0.8V.

400 Ω ~ 40MΩ Range:

### B. DC Voltage

Range	Resolution	Accuracy	Overload Protection	
400mV	0.1mV	±(0.8%+3)	1000V DC	
4V	1mV		750V AC rms	
40V	10mV	±(0.8%+1)	continuous.	
400V	100mV			
1000V	1V	±(1%+3)		
Remark: Input impedance ≥10M Ω.				

# C. Continuity, Diodes & Resistance

• Continuity Test (400.0 Ω ) Range:

Open circuit voltage approximate 0.45V.

Open circuit voltage approximate 1.48V.

Open circuit voltage approximate 0.45V.

Displays approximate forward voltage drop

Buzzer beeps continuously.

5. Continuity, Diodes & Resistance					
Range	Resolution	Accuracy	Overloa Protecti		
Continuity $(400.0 \Omega)$	0.1Ω	Approximate $\leq 100\Omega$			
Diode	1mV	N/A			
400Ω	0.1Ω	<u>+</u> (1.2%+2)	600Vp		
4kΩ	1Ω		00070		
40kΩ	10Ω	±(1%+2)			
400kΩ	100Ω	]			
4MΩ	1kΩ	±(1.2%+2)			
40MΩ	10kQ	$\pm (1.5\% + 2)$			



If the display shows any other value, have the Meter serviced and contact your dealer

test again.

immediately.

A Warning

To replace the battery:

F22 or 006P).

the screw.

A Warning

with the following procedure

out the fuse from its bracket.

Φ5x20mm

φ 5x20 mm

fin the bracket.

the screw.

The

Mete r

D-sub 9 Pin

Male

2

3

4

5

6

7

8

and 2 rubber feet

RS232C Serial Port

A. RS232C Port Cable

To replace the Meter's fuse

it to your dealer for repair

If the Meter does not work while the fuse is all right, send

C. Replacing the Battery (See Figure 11)



To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator "

1. Press the **POWER** to turn the Meter off and remove all

connections from the terminals

- 2. Remove the screw from the battery compartment, and separate the battery compartment from the case bottom.
- 3. Remove the battery from the battery compartment 4. Replace the battery with a new 9V battery(NEDA1604,

5. Rejoin the case bottom and battery compartment, and reinstall

D. Replacing the Fuses (See Figure 12)



To avoid electrical shock or arc blast, or personal njury or idamage to the Meter, use specified fuses ONLY in accordance

- 1. Press the **POWER** to turn the Meter off and remove all
- connections from the terminals
- 2. Remove the screw from the battery compartment, and separate the battery compartment from the case bottom.
- 3 Remove the 2 rubber feet and 2 screws from the case bottom and separate the case top from the case botton
- 4. Remove the fuse by gently prying one end loose, and then take
- 5. Install ONLY replacement fuses with the identical type and specification as follows and make sure the use is fixed firmly
  - Fuse 1:0.5A, 250V, fast type Glass fuse,
  - Fuse 2: 10A, 250V, fast type Glass fuse,
- 6. Rejoin the battery compartment and the case top, and reinstall
- 7. Rejoin the case bottom and case top, and reinstallthe 2 screws
- Replacement of the fuses is seldom required. Burning of a fuse always results from improper operation

Computer				
D-s ub 9 Pin Female	25 Pin Pin Namo		Remark	
. 2	3	RX	Receiving Data	
3	2	TD	Transmitting Data	
4	20	DTR	Data Terminal Ready	
5	7	GND	Grounding	
6	6	DSR	Data Set Ready	
. 7	4	RTS	Request To Send	
8	5	CTS	Clear To Send	

### B. Setting of RS232C Serial Ports

Default of RS232C serial port for communication is set as:

Baud Rate	2400
Start bit	1 (always 0)
Stop bit	1 (always 1)
Data bits	8
Parity	1 (Odd)

#### C. System Requirements for Installing the UT60A Interface Program

To use UT60A Interface Program, you need the following hardware and software:

- An IBM PC or equivalent computer with 80486 or higher processor and 640 x 480 pixel or better monitor.
- Microsoft Windows 95 or above.
- At least 8MB of RAM.
- At least 8MB free space in hard drive
- Can access to a local or a network CD-ROM. A free serial port.
- A mouse or other pointing device supported by Windows. Please refer to the included "Installation Guide & Computer Interface Software" for installing and operating

instructions of the UT60A Interface Program.

~ END ~ This operating manual is subject to change without notice

Manufacturer: Uni-Trend Technology (China) Limited No 6, Gong Ye Bei 1st Road Songshan Lake National High-Tech Industrial Development Zone, Dongguan City Guangdong Province China Postal Code:523 808 Headquarters: Headquarters: Uni-Trend Group Limited Rm901, 9/F, Nanyang Plaza 57 Hung To Road Kwun Tong Kowloon, Hong Kong Tel: (852) 2950 9168 Fax: (852) 2950 9303 Email: info@uni-trend.com http://www.uni-trend.com