



USER GUIDE

LiFePO4 Battery System for Households



Contents

| | |
|--|----|
| 1.ABOUT THIS MANUAL | 1 |
| 1.1 Purpose | 1 |
| 1.2 Scope | 1 |
| 1.3 Safety Instructions | 1 |
| 2.INTRODUCTION | 2 |
| 2.1 Features | 2 |
| 2.2 Product Over View | 2 |
| 2.3 Mounting the Unit | 8 |
| 2.4 Specifications | 9 |
| 3.INSTALLATION | 10 |
| 3.1 Diagram of accessories | 10 |
| 3.2 Description of accessories | 10 |
| 3.3 Precautions for Installing Batteries | 10 |
| 3.4 Installation steps | 10 |
| 4.Product Over View | 16 |
| 4.1 Connection step | 16 |
| 4.2 Communication introduction | 18 |
| 4.3 Interface definition..... | 18 |
| 4.4 Switch ON /OFF | 20 |
| 4.5 ON/ OFF or soC Led (Mode or soC) | 20 |
| 4.6 Connection for Parallel Mode | 22 |
| 5.EMERGENCY SITUATIONS | 23 |
| 5.1 Fire | 23 |
| 5.2 Leaking Batteries | 23 |
| 5.3 Wet Batteries | 23 |
| 5.4 Warranty | 23 |

1 ABOUT THIS MANUAL

1.1 Purpose

This manual describes the introduction, installation, operation and emergency situations of the battery bank. Please read this manual carefully before installations and operations. Keep this manual for future reference.

1.2 Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

1.3 Safety Instructions



WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
2. CAUTION --- To reduce risk of injury, damage, even burst. please use it following using manual. In case of causing personal
3. Do not disassemble the battery. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of fire.
4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. CAUTION – Only qualified personnel can install this device with inverter.
6. For optimum operation of this battery, please follow required spec to select appropriate cable size.
7. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion or fire.
8. Please strictly follow installation procedure.

1.4 Can be connected in parallel

1. The batteries can be connected in parallel. Series connection is not allowed. Use in upright position only.
2. The batteries are not allowed to connected with PWM controller for charging.

Special Attention: Due to the built-in protection board of the lithium battery pack is with over-discharge protection function, it is strongly recommended to stop using the load when the battery pack is over-discharged. The battery pack cannot be repeatedly activated for discharge. Therefore, when the battery pack is low power, please charge the battery as soon as possible when main power or solar energy is available.


2.INTRODUCTION

The battery main using for energy storage system. Built-in smart BMS to match various of hybrid inverters.

2.1 Features

- LiFePO4 Battery.
- Long warranty period:5 years.
- Higher energy density, smaller volumn.
- This battery pack is designed for energy storage systems.
- Support connected in parallel mode for expansion.
- Battery management system(BMS): The battery packs built-in BMS monitors itsoperation and prevents the battery from operating outside design limitations.
- Expandability:This battery pack can be easily expanded by adding expansion battery packs in parallel connection.

2.2 Product Over View (KMD-PL Series)






LiFePO4 Battery System for Households

| No. | Name | Function Description |
|------------|-------------------------------|--|
| 1 | Power Positive Terminal | Power positive output, two terminals with the same positive terminal is a parallel output |
| 2 | RS485 Communication Interface | 1. Testing battery performance 2. When multiple batteries are used in parallel, it acts as a communication connection port between batterie |
| 3 | RS232 Communication Interface | Testing and modifying battery parameters |
| 4 | CAN Communication Interface | Connection to CAN port of inverter |
| 5 | RS485 Communication Interface | Connection to RS485 port of inverter |
| 6 | DRY Communication Interface | DRY output terminal Dry contact 1-PIN1 to PIN2: Normally open, closed when fault protection; Dry contact 2-PIN3 to PIN4: Normally open, alarm closed when low battery |
| 7 | ADD Address Switch | When connecting batteries in parallel by dialing the code Address identification of different batteries (see attached page for dialing rules) |
| 8 | RST Button (Electronic) | 1. You can turn on and off the battery, the default is automatically turned on when the power switch is turned on, long press for 3 seconds, when the power indicator is flashing, release to automatically turn off the battery output 2. After battery troubleshooting, if the ALM indicator is still on, press the RST button for 3-5 seconds, when the power indicator is flashing, release the ALM indicator to turn off |
| 9 | Power Negative Terminal | Power negative output, two terminals with negative terminal is parallel output |
| 10 | Power Switch | Turn on and off the battery |
| 11 | Display | Display all basic parameters of the battery |
| 12 | 4 Display Buttons | MENU ENTER DOWN ESC |
| 13 | RUN Indicator | The indicator light is on to indicate that the battery is |
| 14 | ON/OFF Indicator | The indicator light is on to indicate that the battery is on |
| 15 | ALM Indicator | The indicator light is on to indicate a battery alarm or fault |
| 16 | 6 Power Indicators | Different power levels show different number of indicators |

LiFePO4 Battery System for Households

(KMD-PC Series)







LiFePO4 Battery System for Households

| No. | Name | Function Description |
|------------|-------------------------------|--|
| 1 | Power Positive Terminal | Power positive output, two terminals with the same positive terminal is a parallel output |
| 2 | RS485 Communication Interface | 1. Testing battery performance 2. When multiple batteries are used in parallel, it acts as a communication connection port between batterie |
| 3 | RS232 Communication Interface | Testing and modifying battery parameters |
| 4 | CAN Communication Interface | Connection to CAN port of inverter |
| 5 | RS485 Communication Interface | Connection to RS485 port of inverter |
| 6 | DRY Communication Interface | DRY output terminal Dry contact 1-PIN1 to PIN2: Normally open, closed when fault protection; Dry contact 2-PIN3 to PIN4: Normally open, alarm closed when low battery |
| 7 | ADD Address Switch | When connecting batteries in parallel by dialing the code Address identification of different batteries (see attached page for dialing rules) |
| 8 | RST Button (Electronic) | 1. You can turn on and off the battery, the default is automatically turned on when the power switch is turned on, long press for 3 seconds, when the power indicator is flashing, release to automatically turn off the battery output 2. After battery troubleshooting, if the ALM indicator is still on, press the RST button for 3-5 seconds, when the power indicator is flashing, release the ALM indicator to turn off |
| 9 | Power Negative Terminal | Power negative output, two terminals with negative terminal is parallel output |
| 10 | Power Switch | Turn on and off the battery |
| 11 | Display | Display all basic parameters of the battery |
| 12 | 4 Display Buttons | MENU ENTER DOWN ESC |
| 13 | RUN Indicator | The indicator light is on to indicate that the battery is |
| 14 | ON/OFF Indicator | The indicator light is on to indicate that the battery is on |
| 15 | ALM Indicator | The indicator light is on to indicate a battery alarm or fault |
| 16 | 6 Power Indicators | Different power levels show different number of indicators |

LiFePO4 Battery System for Households

(KMD-PJ Series)




LiFePO4 Battery System for Households

| No. | Name | Function Description |
|------------|-------------------------------|---|
| 1 | Power Positive Terminal | Power positive output, two terminals with the same positive terminal is a parallel output |
| 2 | ON/OFF Indicator | The indicator light is on to indicate that the battery is on |
| 3 | RST Button (Electronic) | <p>1. You can turn on and off the battery, the default is automatically turned on when the power switch is turned on, long press for 3 seconds, when the power indicator is flashing, release to automatically turn off the battery output</p> <p>2. After battery troubleshooting, if the ALM indicator is still on, press the RST button for 3-5 seconds, when the power indicator is flashing, release the ALM indicator to turn off</p> |
| 4 | ADD Address Switch | When connecting batteries in parallel by dialing the code Address identification of different batteries (see attached page for dialing rules) |
| 5 | DRY Communication Interface | <p>DRY output terminal</p> <p>Dry contact 1-PIN1 to PIN2: Normally open, closed when fault protection;</p> <p>Dry contact 2-PIN3 to PIN4: Normally open, alarm closed when low battery</p> |
| 6 | RUN Indicator | The indicator light is on to indicate that the battery is functioning normally |
| 7 | ALM Indicator | The indicator light is on to indicate a battery alarm or fault |
| 8 | 6 Power Indicators | Different power levels show different number of indicators |
| 9 | CAN Communication Interface | Connection to CAN port of inverter |
| 10 | RS485 Communication Interface | Connection to RS485 port of inverter |
| 11 | RS232 Communication Interface | Testing and modifying battery parameters |
| 12 | RS485 Communication Interface | <p>1. Testing battery performance</p> <p>2. When multiple batteries are used in parallel, it acts as a communication connection port between batterie</p> |
| 13 | Power Negative Terminal | Power negative output, two terminals with negative terminal is parallel output |
| 14 | Power Switch(Mechanical) | Turn on and off the battery |
| 15 | Display | Display all basic parameters of the battery |
| 16 | 4 Display Buttons | MENU ENTER DOWN ESC |


2.3 Mounting the Unit

Consider the following points before selecting where to install:

- Do not mount the battery on flammable construction materials.
- The ambient temperature should be between 0°C and 45°C to ensure optimal operation.
- The recommended installation position is to be adhered to the wall vertically.
- Be sure to keep other objects and surfaces as shown in the right diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.
- Refer to the attached figure for installation hole positions and screw hole sizes of wall mounting supports.



(KMD-PL、PC Series)



(KMD-PJ Series)


LiFePO4 Battery System for Households

2.4 Specifications

| | | | | | | |
|-----------------------------|---|----------------------|----------------------|----------------------|----------------------|----------------------|
| Battery Specifications | KMD PJ/PL/PC24100 | KMD PJ/PL/PC24200 | KMD PJ/PL/PC48100 | KMD PJ/PL/PC48200 | KMD PJ/PL/PC51100 | KMD PJ/PL/PC51200 |
| ELECTRICAL | | | | | | |
| Nominal Voltage | 24V/48V/51.2V | | | | | |
| Energy Capacity | 100Ah (2.56KWH) | 200Ah (5.12KWH) | 100Ah (4.8KWH) | 200Ah (9.6KWH) | 100Ah (5.12KWH) | 200Ah (10KWH) |
| Battery Type | LFP(LiFePO4) | | | | | |
| Depth Of Discharge (DoD) | DoD 80% | | | | | |
| OPERATION | | | | | | |
| Max. Charging Current | 90A @25°C | 90A @25°C | 90A @25°C | 90A @25°C | 90A @25°C | 90A @25°C |
| Max. Discharging Current | 100A @25°C | 100A @25°C | 100A @25°C | 100A @25°C | 100A @25°C | 100A @25°C |
| Recommend Charging Voltage | 28V | 28V | 52.5V | 52.5V | 56V | 56V |
| Cut Off Voltage | 24V | 24V | 45V | 45V | 48V | 48V |
| Operating Temperature Range | 0°C~+50°C(Charging)/-20°C~+60°C(Discharging) | | | | | |
| Storage Temperature Range | -30°C~+60°C | | | | | |
| Humidity | 5%~ 95% | | | | | |
| BMS | | | | | | |
| Modules Connection | Max 15 Batteries In Parallel | | | | | |
| Power Consumption | <2 W | | | | | |
| Communication | RS485/RS232/CAN(Optional) | | | | | |
| PHYSICAL | | | | | | |
| Dimensions (Lx W x H)(mm) | 345x336x146 | 547x461x163 | 547x461x163 | 547x471x248 | 542x461x163 | 547x471x248 |
| Weight | 23KGS | 45KGS | 45KGS | 89KGS | 45KGS | 89KGS |
| Option | Wheels | | | | | |
| Ingress Protection Rating | IP20 | | | | | |
| Cycle life | Around 6000 Times | | | | | |
| Warranty | 5 Years Product Warranty, 10 Years Design Life Warranty | | | | | |
| CERTIFICATE | | | | | | |
| Certificate | CE/UN38.3/MSDS | | | | | |

3. INSTALLATION

3.1.1 Diagram of accessories (KMD-PJ Series)




3.2.1 Description of accessories

| No. | Part Name | Specification |
|-----|---|---|
| 1 | Battery | KMD-PJ24100/KMD-PJ48100/KMD-PJ48200 |
| 2 | Expansion screws | Outer hexagon expansion screw GB/T5285-1985-M10X80-8.8 |
| 3 | Output negative power cable | According to different battery specifications and customer needs, match the corresponding output negative power line |
| 4 | Output positive power cable | According to different battery specifications and customer needs, match the corresponding output positive power line |
| 5 | Load-bearing walls | 1. If one battery is hung on the wall: the load-bearing wall of models KMD-PJ4850 and KMD-PJ48100 is 100KG 2. If one battery is hung on the wall: the load-bearing wall of models KMD-PJ48150, KMD-PJ48200 and KMD-PJ48300 is 200KG 3. If multiple batteries are hung on a load-bearing wall, the load-bearing capacity will increase accordingly |
| 6 | Communication line between inverter and battery | According to different inverters and customer needs, the corresponding communication network cable is equipped. If the customer does not inform the inverter of the detailed information, we will not provide this communication network cable. |

3.3.1 Installation steps (KMD-PJ Series)


| Assembly and commissioning step number | Name | Assembly Instructions |
|--|--|---|
| step 1 | Fixed expansion screw | a. Fasten the expansion screw to the load-bearing wall |
| step 2 | Wall mounted battery | b. Fasten the battery to the expansion screw |
| step 3 | Pair plugging positive and negative power cables | c. Insert the positive and negative power cord pairs between the battery and the inverter |
| step 4 | Docking inverter and battery communication cable | d. According to the communication protocol port of the inverter, one end of the communication line between the inverter and the battery is plugged into the CAN or RS485 port of the battery, and the other end is plugged into the inverter. |
| step 5 | Dial the ADD address switch | e. If it is a battery, dial 1, and the rules of other dialing addresses are detailed in the attached page. |
| step 6 | turn on the switch | f. Press the power switch on the side to let the ON/OFF RUN 6 battery indicator lights display in green |

3.4.1 Precautions for Installing Batteries



| Install the machine | |
|---|--|
| Before choosing an installation location, consider the following: | |
| 1 | Do not install the battery on flammable building materials |
| 2 | Mount on a solid wall |
| 3 | Install this inverter at eye level to read the LCD display at all times |
| 4 | To ensure optimum operation, the ambient temperature should be between 0 ° C and 55 ° C. Vertical wall installation is recommended |
| 5 | Make sure there is a certain amount of free space around the inverter, as shown on the right, to ensure adequate heat dissipation and enough room to move the wires. |
| Suitable for installation on concrete or other non-combustible surfaces | |

3.1.2 Diagram of accessories (KMD-PL Series/KMD-PC Series)



3.2.2 Description of accessories


| No. | Part Name | Specification |
|-----|--|---|
| 1 | Battery | KMD-PLPC4850/KMD-PLPC48100/KMD-PLPC48150/KMD-PLPC48200 |
| 2 | Caster wheel | Different products with corresponding castors |
| 3 | Screws | Screw-Stainless steel natural color-Passivated-M6x10-Machine tooth-Crossed flat head-No combination |
| 4 | Mounting ears on the back of the battery | Mounting ears on the back of the battery SPCC surface powder-coated black matte fine sand pattern-80x35x15mm-wall thickness 2mm-3 through-holes with a diameter of 7mm are integrally formed |
| 5 | Screws | Match the corresponding screws according to the casters |
| 6 | Load-bearing walls | 1. If one battery is hung on the wall: the load-bearing wall of models KMD-4850 and KMD-48100 is 100KG 2. If one battery is hung on the wall: the load-bearing wall of models KMD-48150, KMD-48200 and KMD-48300 is 200KG 3. If multiple batteries are hung on a load-bearing wall, the load-bearing capacity will increase accordingly |

| | | |
|----|---|--|
| 7 | Wall Mount Bracket | Corresponding wall brackets are equipped according to different battery specifications |
| 8 | Expansion screws | Outer hexagon expansion screw GB/T5285-1985-M10X80-8.8 |
| 9 | Output negative power cable | According to different battery specifications and customer needs, match the corresponding output negative power line |
| 10 | Output positive power cable | According to different battery specifications and customer needs, match the corresponding output positive power line |
| 11 | Communication line between inverter and battery | According to different inverters and customer needs, the corresponding communication network cable is equipped. If the customer does not inform the inverter of the detailed information, we will not provide this communication network cable. |

3.3.2 Installation steps

| Assembly and commissioning step number | Name | Assembly Instructions |
|--|--|--|
| step 1 | Assemble casters | a.Lock the casters to the bottom of the battery with screws |
| step 2 | Assembled battery back lugs | b.Lock the wall hook to the back of the battery with screws |
| step 3 | Assembling wall brackets | c.Screw expansion screws to the load-bearing wall |
| step 4 | Wall Mount Battery | d.Hang the battery on the wall mount |
| step 5 | Pair plugging positive and negative power cables | e.Insert the positive and negative power cord pairs between the battery and the inverter |
| step 6 | Docking inverter and battery communication cable | f.According to the communication protocol port of the inverter, one end of the communication line between the inverter and the battery is plugged into the CAN or RS485 port of the battery, and the other end is plugged into the inverter. |
| step 7 | Dial the ADD address switch | g.If it is only one battery, please dial 1, and the rules of other dialing addresses are detailed in 4.4 |
| step 8 | turn on the switch | h.Press the power switch on the side to let the ON/OFF RUN 6 battery indicator lights display in green |

3.4.2 Precautions for Installing Batteries



| Install the machine | |
|---|--|
| Before choosing an installation location, consider the following: | |
| 1 | Do not install the battery on flammable building materials |
| 2 | Mount on a solid wall |
| 3 | Install this inverter at eye level to read the LCD display at all times |
| 4 | To ensure optimum operation, the ambient temperature should be between 0 ° C and 55 ° C. Vertical wall installation is recommended |
| 5 | Make sure there is a certain amount of free space around the inverter, as shown on the right, to ensure adequate heat dissipation and enough room to move the wires. |
| Suitable for installation on concrete or other non-combustible surfaces | |

4. INVERTER CONNECTION

CAUTION

As different inverters have different connection rules, please find the battery connection rules in the inverter user manual and follow it. Here list the basic connection step between our battery and unknown brand inverter for your reference.

WARNING

Cut off main power before operation the inverter and battery, after connection and setting is done, Turn on the main power.

4.1 Connection step

Please follow reference steps to implement the connection between battery and inverter:

1. Check the inverter user manual or confirm with the inverter reseller whether the inverter have communication BMS internal:

1) If inverter is without communication BMS RS485/CAN, treat our lithium ion battery as AGM battery

① Connect the positive and negative cables between battery and inverter +/+, -/- (Check the ring terminal size in inverter user manual, make sure it's workable and connect battery and inverter)

② Select "AGM" mode (Sealed lead acid battery) in the inverter

③ Setting the battery data on inverter like charging voltage, charging cut off voltage, discharging cut off voltage, charging current, charging cut off current, discharging current etc (You can consult battery seller to get those data) **WARNING:** Set those data before use, otherwise it will damage the battery!

2) If inverter has communication BMS internal, See step NO.2

2. Check the "**Battery connection**" part from inverter user manual, Find the positive and negative cables' ring terminal size and connect the cables. Make sure polarity at both the

battery and the inverter/charge is correctly connected and ring terminals are tightly screwed to the inveter terminal.

3.Check the inverter user manual to know inverter communication type(RS485 or CAN),and then Find the corresponding communication type(RS485 or CAN) in "**(4.3)Interface definition**" of battery user manual,The inverter communication network port definition must be consistent with our battery's interface definition, otherwise the connection cannot be successful between inverter and our battery.

4.Find the "**(4.4)Dialer switch**" rules in the battery user manual. If it's only one battery, please dial 1. For more quantities battery connection, please refer to the table about dialer switch

5.Select Lithium ion battery mode on the inverter, some inverter need select BMS brand,please follow the real inverter user manual for the complete setting,consult with battery seller if unknow battery data requested on inverter.

6.Switch on the battery pack, use the RS232 communication converter to connect the battery and your laptop, install the BMS management software on the laptop (**Please contact the battery seller for detailed steps**). Check whether the communication protocol CAN and RS485 are correctly selected in the BMS management software setting interface. (If there is no inverter communication protocol corresponding to the brand name, please ask for communication protocol document from inverter seller and sent to the battery seller or switch the "AGM" (Sealed lead acid battery) mode on the inverter firstly, please refer to above NO. 1) ①②③)

7.Turn on the main power,and select the priority mode in the inverter according to your demand.

TIPS: It's only a basicly guideline about the inverter and battery connection above. The accurate connection way is only refer to the real inverter user manual.

4.2 Communication introduction

RS232

BMS can communicate with the upper computer through RS232 interface, so that the upper computer can monitor all kinds of battery information, including battery voltage, current, temperature, status and battery production information, etc. The default baud rate is 9600bps.

CAN


CAN communication, the default communication rate is 500K.

RS485

With dual RS485 interfaces, you can view PACK information, and the default baud rate is 9600bps. If you need to communicate with the monitoring device through RS485, the monitoring device is the host, polling data according to the address, The address setting range is 1~15.

4.3 Interface definition

Communication Interface Diagram




CAN and RS485 interface




1 2 3 4

Dry contact



Parallel communication port



RS232 communication port

Electrical Interface Definition

| RS232 - -Adopt 6P6C vertical RJ11 socket | |
|--|------------------------|
| RJ11 pin | Definition description |
| 2 | NC |
| 3 | TX (vener) |
| 4 | RX (vener) |
| 5 | GND |

| CAN- - adopts 8P8C vertical RJ45 socket | | RS485 - - 8P8C vertical RJ45 socket | |
|---|-----------|-------------------------------------|-----------|
| RJ45 pin | Specifies | RJ45 pin | Specifies |
| 1、 2、 3、 6、 8 | NC | 1、 8 | RS485-B1 |
| 5 | CANL | 2、 7 | RS485-A1 |
| 4 | CANH | 3、 6 | GND |
| 7 | GND | 4、 5 | NC |

CAN and RS485 interface


| RS485 - - 8P8C vertical RJ45 socket | | RS485 - - 8P8C vertical RJ45 socket | |
|-------------------------------------|-----------|-------------------------------------|-----------|
| RJ45 pin | Specifies | RJ45 pin | Specifies |
| 1、 8 | RS485 - B | 1、 8 | RS485-B1 |
| 2、 7 | RS485-A | 2、 7 | RS485-A1 |
| 3、 6 | GND | 3、 6 | GND |
| 4、 5 | NC | 4、 5 | NC |

Parallel communication port

Once the batteries are connected well, simply press On/Off button to enable the output of the battery pack.

4.4 Dial Switch

When PACK is used in parallel, different PACK can be distinguished by setting the address of ADD switch on BATTERY , and it is necessary to avoid setting the address to be the same. For the definition of BMS ADD switch, refer to the following table.



| Address | Dial code switch position | | | |
|---------|---------------------------|-----|-----|-----|
| | # 1 | #2 | #3 | #4 |
| 0 | OFF | OFF | OFF | OFF |
| 1 | ON | OFF | OFF | OFF |
| 2 | OFF | ON | OFF | OFF |
| 3 | ON | ON | OFF | OFF |
| 4 | OFF | OFF | ON | OFF |
| 5 | ON | OFF | ON | OFF |
| 6 | OFF | ON | ON | OFF |
| 7 | ON | ON | ON | OFF |
| 8 | OFF | OFF | OFF | ON |
| 9 | ON | OFF | OFF | ON |
| 10 | OFF | ON | OFF | ON |
| 11 | ON | ON | OFF | ON |
| 12 | OFF | OFF | ON | ON |
| 13 | ON | OFF | ON | ON |
| 14 | OFF | ON | ON | ON |
| 15 | ON | ON | ON | ON |

4.5 ON/ OFF or soC Led (Mode or soC)

LED instructions

Table 1 LED Working status indication

| State | Normal / Alarm / Protection | ON/OFF | RUN | ALM | SOC Indication LEDs | | | | | | Instructions | |
|-----------|--|--------|--------|--------|--|-----|-----|-----|-----|-----|---|------------------------------------|
| | | ● | ● | ● | ● | ● | ● | ● | ● | ● | | |
| Power Off | Sleep | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | All off |
| Standby | Normal | ON | Flash1 | OFF | Indication by SOC | | | | | | Standby | |
| | A larm | ON | Flash1 | Flash3 | Indication by SOC | | | | | | Cell low voltage | |
| Charge | Normal | ON | ON | OFF | Indication by SOC (The top SOC Led Flash 2) | | | | | | Maximum power LED flash(Flash2), ALM does not flash for over- charge warning | |
| | A larm | ON | ON | Flash3 | Indication by SOC | | | | | | | |
| | Over Charge Protection | ON | ON | OFF | ON | ON | ON | ON | ON | ON | ON | If no mains supply, LED as standby |
| | Temperature. Over- current Fault Protection | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | Close charge |
| Discharge | Normal | ON | Flash3 | OFF | Indication by SOC | | | | | | | |
| | A larm | ON | Flash3 | Flash3 | Indication by SOC | | | | | | | |
| | Under Discharge Protection | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF | Close discharge |
| | Temperature. Over- current. Short Circuit Fault Protection | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | Close discharge |
| Fault | | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | Close charge Close discharge |

LiFePO4 Battery System for Households

Table 2 Capacity indication

| State | | Charge | | | | | | Discharge | | | | | |
|--------------------------|------------|--------|--------|--------|--------|-----|--------|----------------|-----|-----|-----|-----|----|
| Capacity indicator light | | L6 | L5 | L4 | L3 | L2 | L1 | L6 | L5 | L4 | L3 | L2 | L1 |
| electricity(%) | 0~16.6% | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| | 16.6~33.2% | OFF | OFF | OFF | OFF | OFF | Flash2 | OFF | OFF | OFF | OFF | OFF | ON |
| | 33.2~49.8% | OFF | OFF | OFF | Flash2 | ON | ON | OFF | OFF | OFF | ON | ON | ON |
| | 49.8~66.4% | OFF | OFF | Flash2 | ON | ON | ON | OFF | OFF | ON | ON | ON | ON |
| | 66.4~83.0% | OFF | Flash2 | ON | ON | ON | ON | OFF | ON | ON | ON | ON | ON |
| | 83.0~100% | Flash2 | ON | ON | ON | ON | ON | ON | ON | ON | ON | ON | ON |
| Running light ● | | ON | | | | | | Flash(Flash 3) | | | | | |



Table 3 LED Flash description

| Flashing way | ON | OFF |
|--------------|-------|-------|
| FLASH 1 | 0.25S | 3.75S |
| FLASH 2 | 0.5S | 0.5S |
| FLASH 3 | 0.5S | 1.5S |

Note: The LED indicator alarm can be enabled or disabled by the host computer. It is enabled by factory default.

4.6 Connection for Parallel Mode

1. The ADD address of this battery wired with the inverter is 1, other batteries dial the corresponding address according to the dial code address rule
2. Continuous current 100A. 6AWG or 4AWG wire is recommended for the power cord



5.EMERGENCY SITUATIONS

KMD cannot guarantee battery absolute safety.

5.1 Fire

In case of fires, make sure that the following equipment is available near the system.

- SCBA (self-contained breathing apparatus) and protective gear in compliance with the Directive on Personal Protective Equipment 89/686/EEC.
- NOVEC 1230, FM-200, or dioxide extinguisher

Batteries may explode when heated above 130°C. KEEP FAR AWAY from the battery if it catches fire.

5.2 Leaking Batteries

If the battery pack leaks electrolyte, avoid contact with the leaking liquid or gas. If one is exposed to the leaked substance, immediately perform the actions described below.

- Inhalation: Evacuate the contaminated area, and seek medical attention.
- Contact with eyes: Rinse eyes with running water for 5 minutes, and seek medical attention.
- Contact with skin: Wash the affected area thoroughly with soap and water, and seek medical attention.
- Ingestion: Induce vomiting, and seek medical attention.

5.3 Wet Batteries

If the battery pack is wet or submerged in water, do not let people access it, and contact your supplier for help.

Damaged Batteries

Damaged batteries are not fit for use and are dangerous and must be handled with the utmost care. It may leak electrolyte or produce flammable gas. If the battery pack seems to be damaged, pack it in its original container, and then return it to your supplier.

5.4 Warranty

Products that are operated strictly in accordance with the user manual are covered by the warranty. Any violation of this manual may void the warranty.

Any product damage or property loss caused by the following conditions, KMD does not assume any director indirect liability.

- Product modified, design changed or parts replaced.
- Changed, or attempted repairs and erasing of series number or seals;
- System design and installation are not in compliance with standards and regulations;
- The product has been improperly stored in end user's premises;
- Transport damage (including painting scratch caused by movement inside packaging during shipping). A claim should be made directly to shipping or insurance company.

Kamada power



Shenzhen Kamada Electronic Co., Ltd

Web: www.kmdpower.com

E-mail: marketing@kmdpower.com

Address: Building 4, Mashaxuda High-tech Industry Park, Pingdi Street,
Longgang District 518117, Shenzhen, Guangdong, P.R.China.

Fax: +86-755-23229135 Tel: +86-755-2833 2245