LIVE FROM ESKOM

NEUTRAL FROM ESKOM

LIVE FROM INVERTER

NEUTRAL FROM INVERTER

LIVE TO INVERTER.

LIVE TO LOAD.

NEUTRAL TO INVERTER.

NEUTRAL TO LOAD.

CONNECT ALL EARTH TO EARTH BAR.