

# Instruction Manual for Working Lamp

**Part Number: WLP-LED1460 CTED**

**Model Number: 9501LED-7**

Thank you very much for purchasing our Working Lamp. It is ideal for precise work in home, office, workshop as well as a lot of other important places. Before using the lamp, please read the following instructions.

1. Parameter:

- 1) Voltage: 100-240V~ 50/60Hz
- 2) Power: 14W (60 PCS SMD LED)

2. How to use:

Clamp the bracket to the edge of any horizontal surface which you have chosen. Insert the bottom stem of the arm into the hole in the bracket. Plug in the lamp.

3. How to dimming:

- 1) Step dimming switch  
ON-25%-50%-75%-100%-OFF(The data is approximate)
- 2) When the power turned on, the lamp is in the "off" position.
- 3) Our lamp has the function of power memory. When it restarts, first time we press the button, the dimming switch is the one before the power failure.

4. Important for safe use:

- 1) Indoor use only.
- 2) Environment temperature  $-5^{\circ}\text{C}\sim 40^{\circ}\text{C}$ .
- 3) Humidity:  $\leq 95\%$ .
- 4) Never disassemble the working lamp unless you are a qualified electrician.
- 5) Plug must be taken out while repairing the lamp.

5. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.