Professional CCTV System

Micro CCTV Camera

User Manual



Please Read This User Guide Carefully Before Use.












Warning



To prevent fire or electric shock hazarded, do not expose the unit to rain or mositure. And only use the power supply specified for the unit.



This symbol alerts the user to presence of importance operating and maintenance issues according to the manual



Specification Model XY-AHD4007MM 2.0MP PAL System 1/3" 1080P Progressive Scan CMOS sensor **Image Sensor** Picture Elements PAL:1920(H)*108(V) Horizontal Recolution 2.0MP Video OutPut 1.0Vp-p Composite Output (75 Ω / BNC) S/N Ratio ≥48dB Min.Illumination OLUX(IR ON) Electronic Shutter 1/50(1/60)S~1/100,000S White Balance Auto Gamma Ratio >0.45 3.7mm Pinhole lens ens Mount -10°C ∼ +50°C Operating Temp. Humidity 0 to 95%RH(non-condensing) Power/Current **DC 12V** 2:1 Interlace internal Sync. Sync System IR Project Distance IR Status Outdoor/Indoor Indoor Packing list Number Model XY-AHD4007MM 2.0MP Digital CCTV Camera 1 XY-AHD4007MM 2.0MP User Manual

Installation Notice

1.Do not attempt to open the cover unless you are authorized to do so.

2. Handle with care.

3.Do not expose the camera to eroding Environment.

4. Pay attention to keep the surface of

the lens clean. The clearness of the

image can be damaged if the surface is scratched

5.Do not expose the camera to moisture

exceed 85% for a long time.

6.Please do not use strong corrosive

cleaner when clean the surface of the camera.

7. Avoid focusing on the sun or

highlight directly .Avoid working in

spotlight or highlight environment.

8.Set the power voltage according to the Manual.

9. Use the camera within the temperature between -10 ~+50.



Please note the camera's operating temperature and its using environment. Aviod using the camera at too high or too low temperatures.

*Never make the camera face the sun or bright object. otherwise will damge the CCD. *Dont mount the camera near by the radiator or heater.