

UNI REMOTE TX4H 433MHZ BLUE



Remote Control Duplicator User's Manual

Chipset compatible with most 433Mhz remotes.
Fixed and Rolling Code.



CE RoHS

Compatible with the following:

| | | |
|-----------------------------------|------------------|-----------------------|
| 1 BFT MITTO2 MITTO4 (old version) | 2 FAAC XT4 433RC | 3 MotorLine MX4SP DSM |
| 4 BENINCATO GO WV | 5 KEYTXB-42R | 6 DEAMIO TR2 |
| 7 DOORHANTX4 | 8 ATA PTX4 | 9 Peccanin TX3C |
| 10 NICE FLORS | 11 GBDAU1600 | 12 CenturionNOVA |
| 13 V2 | 14 Nice-Smilo | 15 AN MOTOR AT - 4 |
| 16 NOVOFERM | 17 ROSSI | 18 FADINI JUBI |
| 19 Hiland | | |



**BENINCA
ALLMATIC**



**DOORHAN
TX4**



**KEY
TXB-42R**



**GBD
AU1600**



Nice-Smilo



DEA



**FADINI
JUBI**



Novoferm



V2



**FAAC
XT4 433**



ECA



**Motorline
MX4SP DSM**



**BFT
MITTO2/MITTO4**



**NICE
FLORS**



**ATA
PTX-4**



Rossi



**Peccanin
TX3C**



**Centurion
NOVA**

UNI REMOTE TX4H 433MHZ BLUE

Programming Fixed Code (Learn Method)

MEMORY CLEARANCE

- 1.PRESS BUTTON 1 AND 2 SIMULTANEOUS UNTIL LED FLASHES 3 TIMES
2. RELEASE BUTTON 2 (KEEP PRESSING BUTTON 1), AND PRESS BUTTON 2 SLOWLY FOR 3 TIMES, LED FLASHES QUICKLY.
3. RELEASE BOTH BUTTON, THE DUPLICATOR IS READY FOR COPYING

DUPLICATING

PUT DUPLICATOR ASIDE OF ORIGINAL TRANSMITTER, AS CLOSE AS POSSIBLE.

PRESS AND HOLD BUTTON 1 OF ORIGINAL TRANSMITTER, THEN PRESS AND HOLD BUTTON 1 OF DUPLICATOR UNTIL YOU SEE THE DUPLICATOR'S

LED FLASHES MEANS THE DUPLICATING SUCCEED.

REPEAT ABOVE STEP TO THE REST BUTTONS. THE DUPLICATOR WILL WORK AFTER DUPLICATING.

FIXED CODE REMOTE CONTROL:

PRESS AND HOLD BUTTON 1 OF ORIGINAL TRANSMITTER, THEN PRESS AND HOLD BUTTON 1 OF DUPLICATOR UNTIL YOU SEE THE DUPLICATOR'S

LED FLASHES MEANS THE DUPLICATING HAS SUCCEED.

ONCE 1 BUTTON DUPLICATED, THE REST BUTTONS WILL GENERATE AUTOMATICALLY, PLEASE FOLLOW ORIGINAL RECEIVER MANUAL TO INSERT

THE NEW DUPLICATOR ON THE RECEIVER.

PROGRAMMING ROLLING CODE REMOTE CONTROLS :

1, MEMORY CLEARANCE

2, PRESS AND HOLD BUTTON 1 OF DUPLICATOR TILL LED FLASHES TWICE AND OFF, PRESS BUTTON 2 ONCE WHILE KEEP HOLDING BUTTON 1,

THE DUPLICATOR INTO BFT COPYING MODE

3,PRESS AND HOLD BUTTON 1ST &2ND OF BFT SIMULTANEOUS (SEED CODE SENDING MODE), LED ON DUPLICATOR WILL FLASHES TWICE

AND OFF, RELEASE BOTH BFT BUTTONS AND THEN PRESS ANY BUTTON OF BFT, LED ON DUPLICATOR WILL FLASHES THREE TIMES THEN STAY

ON, WHICH INDICATES BFT COPYING DONE.

REMARKS: BUTTON 1 OF DUPLICATOR KEEP PRESSED FROM STEP 2 TILL 3 DONE.

DUPLICATOR TO SEND SEED CODE OF BFT: PRESS BUTTON 1 & 4 SIMULTANEOUS.

SPECIAL PROGRAMMING STEPS FOR BFT MITTO2 & MITTO4 (OLD VERSION)

IF YOU ERASE THE CODE BY MISTAKE, YOU CAN RESUME IT BY PRESSING AND HOLD BOTH OF THE "3" AND "4" BUTTON ON THE REMOTE

CONTROLLERS AT THE SAME TIME, AFTER 10 SECONDS, THE LED FLASHES 2 TIMES AND TURN OFF WHICH INDICATES THE CODE OF THE COPY

REMOTE CONTROLLER IS RESUMED.

RESUME

REMARKS

FOR FIXED CODE &LEARNING CODE REMOTE CONTROLS, THE DUPLICATOR WILL WORK AFTER DUPLICATING.

BUT FOR THE ROLLING CODE BRAND LISTED ABOVE, PLEASE FOLLOW THE ORIGINAL MANUAL TO PROGRAM THE DUPLICATOR TO RECEIVER AFTER DUPLICATING.