## **Specifications:**

- 1.CPU Electronic coin acceptor ,Drop Inserting Type.
- 2 Capable for accepting all worldwide Coins and Tokens.
- 3:Select coin by Diameter, Thickness and Metal Content.
- 4:CPU anti-string programs presetting against fraud.
- 5:Adjustable VR tunning for sensitivity of coin acceptance.
- 6: Allow to connect to Counter(Meter).

Voltage: DC+12V

Coin Diameter : 22mm~28mm
Coin thickness : 1.7mm~2.2mm

## **USER GUIDE:**

- 1. Replace yellow plastic token to the correct coin as wish to accept in sampling clamp.
- 2. Adjust entry slot opening to your coin size by loosening screw on the back of metal panel for blocking bigger invalid coin from inserting.
- 3. Turn the screw on front lid in clockwise direction for ditching "thinner coin" through the slot of lid if necessary.
- 4. switch to Normal Open (N.O.) or Normal close (N.C) for signal output of coin validation upon Host requested .
- 5. 3 triggering TIMER SWITCH of Pulse Duration,
- · Long duration of Pulse :. 100ms
- · Common duration of Pulse : 50ms
- · Short duration of Pulse :30ms
- 6. VR tuning for tolerance of coin acceptance, turn clockwise for slack and anti-clockwise for precise acceptance.
- 7. Shift sensitivity switch of coin acceptance downward to "special" to extend the range of discriminated ratio for twin metal coins or the coins in big tolerance.

## Applications:

- Wireless PC peripherals
- Coin kiosk
- Car washing machine
- TV
- Massage chair
- Cloth dryer
- Cyber coffee
- Laundromat
- Laundry
- Computer
- Amusement machine
- Arcade machine