





The WASP is a USB fingerprint reader configured to work with the Amatec range of readers. It is a convenient way to enroll the fingerprints directly to the Mi-Time Software thus avoiding timeous tasks. Once you have enrolled everyone to the Mi-Time Software via the WASP, you may then upload all fingerprints to the rest of the Amatec readers in the field.

Wasp Product Specifications:

Fingerprint Sensor	Optical Fingerprint Collector
Resolution	500 DPI
Photosensitive Area	14mm*17mm
Image Size	280mm*360mm
Communication Interface	USB 1.0,1.1,2.0
Operating System	Win8/Wini7/Vista/XP (32/64-Bit),Windows Server 2003/2008 (32/64-Bit)