

## FlukeView Forms Software with cable

<b>Specifications</b>	
<b>Operating system for FlukeView Forms</b>	Windows 2000, Windows XP or Windows Vista
<b>Minimum PC Hardware</b>	Pentium class or better microprocessor 32 MB RAM 70 MB hard disk space (100 MB to install) Serial or USB port

Administrator Privileges required to install software on Windows 2000, XP, or Windows Vista

<b>Mechanical &amp; General Specifications</b>	
<b>Size</b>	203 x 100 x 50 mm
<b>Weight</b>	545 g