



User's Manual

Headphone



- 1.SCAN
- 2.Wireless headphone
- 3.Volume -
- 4.Volume +
- 5.Micro USB charging port
- 6.Audio-in
- 7.Indicator
- 8.ON / OFF

Transmitter



- 9.Audio-in
- 10.USB plug

Specification

Headphone

Reception Mode: FM
Frequency range:88-108Mhz
Distortion: 1%
Power Supply:Lithium battery

Transmitter

Modulation mode: FM
Frequency: 86 ± 0.5 MHz
Emission distance: ≤ 30 M
Power supply: USB port

Package Include

● Headphone	1
● Transmitter	1
● User's Manual	1
● Aux Cable	1
● USB Cable	1
● Audio Cable	1(Optional)

Operation

Wireless Headphone


1. The Transmitter inserted into the power supply device with USB port.
(such as power bank, TV, PC,etc)
2. Insert audio plug of the emitter into AUDIO-OUT socket of audio source.
(such as TV, audio device, PC,DVD player, CD player, MP3 player, etc)
3. Press the power switch(8) to "ON", then press the wireless headphone key(2).

Listen to FM Radio

Press the power switch(8) to "ON", then press the "SCAN" key(1) in turn to search a higher range and lock on radio channel.

Wired Headphone

Connect the Headphone and aux cable can be used as wired headphone(fig.3)



Note

1. USB transmitter should keep away from adaptor.
2. Using the power bank or PC,TV USB port supply electricity is best.
3. Recharge the battery if the receiver reception is poor.
4. If have large noise, please turn down the receiver volume and turn up the audio device volume.
5. If the receiver distortion, please turn down the audio device volume.