

## Wiring Information for RH110.. Range Illuminated Switches

Pin 1 = Live IN ( From Supply Socket )

Pin 2 = Live OUT ( To Load )

Pin 3 = Neutral ( For NEON Lamp to turn On )