

Instruction Manual for Magnifier Lamp

Part Number : MLP-LED1260A DTRX5D

Thank you very much for purchasing our Magnifier Lamp.

Dimmable , Desktop Led Magnifier ,Round Cover, LensDiopter X 5D .

-Top Quality Optics

Outstandingly good value ,modern design, top quality, Tilttable and rotatable head includes a very useful hinged cover. Colour - white. Suitable for domestic, industrial, medical and professional use..

Before using the Magnifier Lamp, please read the following instructions.

1. Parameter:

- 1) Lens size: 5”(127mm)
- 2) Lens: 5D
- 3) Voltage: 220-240V 50Hz
- 4) Power: 12W (60pcs LED)

2. How to use:

Put the lamp onto any horizontal surface which you have chosen. Plug in the magnifier lamp, and turn on, repress the “on/off button” for preset dimming options.

3. Important for safe use:

- 1) Indoor use only.
- 2) Environment temperature -5°C~40°C
- 3) Humidity: ≤95% .
- 4) Never disassemble the magnifier lamp unless you are a qualified electrician.
- 5) Plug must be taken out while repairing the magnifier lamp.

4. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

