

Professional CCTV System

IR CCTV Dome Camera

User Manual



Please Read This User Guide Carefully Before Use.



Warning



To prevent fire or electric shock hazardous, expose the unit to rain or moisture. And power supply specified for the unit.




This symbol alerts the user to presence of i operating and maintenance issues accordir manual



Warning

Electronic shock dangerous, Don't open

CONNECTING CCTV SYSTEM



Specification

Model	XY-AHD151FDV 1.0MP 4 IN 1
System	PAL
Image Sensor	HDI8901 + H42
Picture Elements	PAL:1280(H)*720(V)
Horizontal Recolution	1.0 Megapixel
Video OutPut	UP: AHD, Down: CVI, Left: TVI, Right: CVBS
S/N Ratio	≥48dB
Min.Illumination	0LUX(IR ON)
Electronic Shutter	1/50(1/60)S ~ 1/100,000S
White Balance	Auto
Gamma Ratio	> 0.45
Lens Mount	3.6mm MP lens
Operating Temp.	-10°C ~ +50°C
Humidity	0 to 95%RH(non-condensing)
Power/Current	DC 12V
Sync System	2:1 Interlace internal Sync.
IR Project Distance	10M / 24 units F5 LED
IR Status	On
Vandalproof level	IP65

Packing list

Name	Model	Number
Digital CCTV Camera	XY-AHD151FDV 1.0MP 4 IN 1	1
User Manual	XY-AHD151FDV 1.0MP 4 IN 1	1

Installation Notice

1. Do not attempt to open the cover unless you are authorized to do so.
2. Handle with care.
3. Do not expose the camera to eroding Environment.
4. Pay attention to keep the surface of the lens clean. The clearness of the image can be damaged if the surface is scratched
5. Do not expose the camera to moisture exceed 85% for a long time.
6. Please do not use strong corrosive cleaner when clean the surface of the camera.
7. Avoid focusing on the sun or highlight directly .Avoid working in spotlight or highlight environment.
8. Set the power voltage according to the Manual.
9. Use the camera within the temperature between -10 ~+50.



Notes:

- *Please note the camera's operating temperature and its using environmer camera at too high or too low temperatures.
- *Never make the camera face the sun or bright object. otherwise will damg
- *Dont mount the camera near by the radiator or heater.

, do not
only use the

importance
ing to the



eo

DC

-
upply

nt. Avoid using the
ge the CCD.