

Instruction Manual for Magnifier Lamp

Part Number: MLP-LED1684 CTRX5

Thank you very much for purchasing our Magnifier Lamp. It is ideal for precise work in home, office, workshop as well as a lot of other important places. Before using the Magnifier Lamp, please read the following instructions.

1. Parameter:

- a) Lens size: 7" (178mm)
- b) Voltage: 220-240V 50/60Hz
- c) Power: 16W (84pcs SMD LED)

2. How to use:

Clamp the bracket to the edge of any horizontal surface which you have chosen. Insert the bottom stem of the arm into the hole in the bracket. Plug in the magnifier lamp.

3. Important for safe use:

- a) Indoor use only.
- b) Environment temperature $-5^{\circ}\text{C}\sim 40^{\circ}\text{C}$.
- c) Humidity: $\leq 95\%$.
- d) Never disassemble the magnifier lamp unless you are a qualified electrician.
- e) Plug must be taken out while repairing the magnifier lamp.

4. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.